




Magnetic Bike

84-0199-8

Owner's Manual



Questions?

If you have a question or if there are missing parts, please call:

1-866-840-3596

Monday-Saturday 7:00am-8:00 p.m. EST


Model #: 7576BK-5

Product #: 84-0199-8

Serial #: 48527

Purchase Date: _____

Finding
your
serial
number:




Serial
Number
Decal

Monitor Operations Instruction:

REVEAL RULE:

TIME	-----00:00~59.59MIN
SPEED	-----0.00~99.9 KM/H(KM/H)
DISTANCE	-----00.00~99.99 KM (KM)
CALORIE	-----0.00~9999KCAL
PULSE	-----40~220 BPM

Display Functions:



NOTE:

1. Without any signal coming in 4-5 minutes, the LCD display will be shut off automatically.
2. When there is signal input, the monitor automatically turns on.
3. If the display is not showing up correctly, please replace the batteries. If the problem continues, please call 1-866-840-3596.
4. Computer operated by 2 x AA batteries (included)

HOW TO USE

How to get on and off the Magnetic Bike

1. Make sure the bike is stable before using. Fix the seat at a proper height by adjusting the spring bolt.
2. Sit down on the seat and place your feet on the left & right pedals.
3. Push the pedals until they begin to move with a continuous motion. Place both hands on the handlebars.
4. To dismount wait until the pedals come to a complete stop.



MAINTENANCE AND TROUBLESHOOTING

- Check and make sure that all the parts are correctly tightened before using.
- To ensure the level of safety, the equipment must be regularly checked. It is vital that any faulty parts are replaced and make sure it is not used until completely repaired. It is important to grease moving parts frequently.
- Clean sweat and do not leave it to contact with the enameled or chromed parts of the equipment, particularly the computer. Immediately wipe the equipment after training. The enameled parts can be cleaned using a damp sponge. All aggressive or corrosive products should not be used to clean the equipment.
Do not put your equipment in wet area to avoid any rustiness of the parts.
- If the Monitor does not display, check the batteries, if weak or dead, replace them.
- If resistance levels are not adjustable, securely plug tension control cable into the extension tension control cable.
- If the pulse does not display, check the pulse wires are connected well, monitor are working properly. Replace them if necessary.
- Only manufacturer-supplied components shall be used to maintain/repair the equipment.
- **Storage:** When storing the Magnetic bike, remove the batteries from the computer and keep bike in a clean, dry location away from moisture and dust.

PRODUCT DIAGRAM

