


* ADJUST L25/R205 FOR PROPER HORIZONTAL WIDTH

MIT L25/R205 HORIZONTAL-AMPLITUDE EINSTELLEN

REGLER L25/R205 POUR OBTENIR UNE CORRECTE AMPLITUDE HORIZONTALE

REGOLARE L25/R205 PER UNA CORRETTA AMPIEZZA ORIZZONTALE




(TZ)

110* ADJUST R203 FOR PROPER TRAPEZIUM

MIT R203 TRAPEZENTZERRUNG EINSTELLEN

REGLER R203 POUR AJUSTER LE TRAPEZE

REGOLARE R203 PER CORREGGERE IL TRAPEZIO



(TW)



110* ADJUST R200 FOR PROPER PIN-CUSHION

MIT R200 KISSEN EINSTELLEN


REGLER R200 POUR AJUSTER LE COUSSIN

REGOLARE R200 PER CORREGGERE IL CUSCINO

(AGC)



SYMBOLS			
CAPACITORS		RESISTORS	
MELF		MELF	
MYLARD		FUS	
<200V		1/4 W	
200V		1/2 W	
300V		1 W	
400V		2 W	
600V		5 W	
630V			
>650V			





AUTOMATIC GAIN CONTROL
 AUTOMATISCHE VERSTÄRKUNGSREGELUNG
 CONTRÔLE AUTOMATIQUE DU GAIN
 CONTROLLU AUTOMATION OF: GUADAGNO


FOCUS
 BILIOSCHARFE
 FOCUS
 FUOCO



SCREEN GRID
 SCHIRMGITTERSPANNUNG
 TENSION DU GRILLE-ECRAN
 GRIGLIA SCHERMO

88.65.50.387.00 / OTT.96









ADJUSTMENT


EINSTELLANWEISUNG

REGLAGES

REGOLAZIONI

90°

110°



HC

ADJUST R186 TO CENTRE THE PICTURE HORIZONTALLY


MIT R186 HORIZONTALE BILDLAGE EINSTELLEN

REGLER R186 POUR OBTENIR UN CENTRAGE CORRECTE HORIZONTAL

REGOLARE R186 PER UNA CORRETTA CENTRATURA ORIZZONTALE

90°

110°



VA

ADJUST R194 FOR PROPER VERTICAL HEIGHT


MIT R194 VERTIKAL-AMPLITUDE EINSTELLEN

REGLER R194 POUR OBTENIR UNE CORRECTE AMPLITUDE VERTICALE

REGOLARE R194 PER UNA CORRETTA AMPIEZZA VERTICALE

90°

110°



VL

ADJUST R192 FOR PROPER VERTICAL LINE

MIT R192 VERT LINEARITÄT EINSTELLEN

REGLER R192 POUR OBTENIR UNE CORRECTE LINE

REGOLARE R192 PER UNA CORRETTA LINEARITÀ VERTICALE