

---

**Model:** KP-43T70, KP-43T75, KP-46C70, KP-48S70  
KP-48S72, KP-48S75, KP-48V80, KP-48V85  
KP-53N74, KP-53N77, KP-53S70, KP-53S75  
KP-53V80, KP-53V85, KP-61S70, KP-61S75  
KP-61V80, KP-61V85

**No. 468R1**

**Subject: Self Diagnosis Display Correction**

**Date:** May 11, 2001

**Symptom:**

**(xxxx)** The Self-Diagnosis Display Clearing directions are incorrect.

**Solution:** Please add the corrected information to the Service Manual.

**SELF-DIAGNOSIS DISPLAY**

To clear the failure results, perform the following sequence on the remote:

- 1.) Start with set in Stand-By mode (i.e. AC is applied, but TV is off)
- 2.) Press <DISPLAY>, <CHANNEL 5>, **<VOL down>**, & <TV POWER> to power the Set-up in self-diagnosis mode.
- 3.) Press channel <8> and <ENTER> to clear the display. (All items should display 000 after this step.)
- 4.) To exit this mode turn TV off then back on again.

**SERVICE MODE**

To return TV to factory preset conditions:

- 1.) Start with set in Stand-By mode (i.e. AC is applied, but TV is off)
- 2.) Press <DISPLAY>, <CHANNEL 5>, **<VOL up>**, & <TV POWER> to power the set-up in service mode.
- 3.) Press channel <8> and <ENTER> to perform a TEST RESET. (The set will now be in the factory-preset condition.)
- 4.) To exit this mode turn TV off then back on again.