


F DVDREG CIRCUIT

[illegible]



SCHEMATIC DIAGRAM - 21

F DVDREG CIRCUIT

TO B
DVD MODULE(2) CIRCUIT (FP3202)
ON SCHEMATIC DIAGRAM-13




I CD DETECT CIRCUIT




H SPINDLE POSITION CIRCUIT

- | | |
|----------------------------------|-----------------------------------|
| Q708
KTA1046YU
REGULATOR | Q711
2SC2412KT96R
REGULATOR |
| Q709
2SD2114K1V
REGULATOR | Q712
2SB621ARSTA
REGULATOR |
| Q710
2SB621ARSTA
REGULATOR | Q713
2SC2412KT96R
REGULATOR |
| Q703
KTA1046YU
REGULATOR | Q704
2SC2412KT96R
REGULATOR |

G CD LOADING CIRCUIT



TO F
DVDREG
CIRCUIT
(CN1) ON
SCHEMATIC
DIAGRAM-22



TO N
SUB-TRANSFORMER CIRCUIT
(W705) ON SCHEMATIC DIAGRAM-27

SCHEMATIC DIAGRAM - 22

— : +B SIGNAL LINE - - : -B SIGNAL LINE

F DVDREG CIRCUIT

TO MAIN CIRCUIT
(CP701) ON
SCHEMATIC
DIAGRAM-25

TO CD LOADING
CIRCUIT
(CN1) ON
SCHEMATIC
DIAGRAM-21

