

SCHEMATIC DIAGRAM -3

B MAIN CIRCUIT

: Rec Signal line
 : AM/FM Signal line
 : Main Signal line
 : +B Line
 : Playback Signal line
 : CD Signal line

TO TUNER CIRCUIT (1A) on SCHEMATIC DIAGRAM-11

TO CASSETTE DECK CIRCUIT (H1304) on SCHEMATIC DIAGRAM-9

TO PANEL CIRCUIT (CP605) on SCHEMATIC DIAGRAM-6

