




## 3139 123 5673.1









# A9 FRONT CONTROL







# DVD POWER SUPPLY (RESERVED)




3139 123 5673.1








## SIDE AV PANEL + HP PANEL



### Features & Connectivities




HEADPHONE

**SPEAKER**

EcoSub

# E TOP CONTROL (PV2)











EUROPE 220V - 240V




3139 123 5673.1

E 1440 002.2

1900







A6336K

A6337K

A6335K

A6334K

3330  
4330

2333


3337  
4337

2335

4329  
3329  
4328  
3328

2334

2331  
3357



2332

2376  
A K  
6376  
J

E B  
3376  
3376

K A  
6361  
J

3361  
3387

C  
7361  
B E

C  
7362  
B E

C  
7331  
B E

2365  
3389  
3369  
3386  
3368

3390

E B  
7332  
C

4370

2383

2385

3370

3383

3386  
4374  
3374

A6381K  
E B  
7366  
C

2382  
3384

3385


3375


3363


3366

3365


2384














4610  
3610

4630  
A 6610K

2610

A6611K

3627 7627 E B  
C  
3612 K6625 A 3628

4637

4611  
4612  
4613  
2606

16 9  
1 8  
7611

2613  
2615  
2617  
2616  
2614

2618  
3621  
3620  
3619

4617

3613  
3614  
3615

2627

4614

24 13  
1 12  
7610  
4633  
4634


4631  
3636  
4632  
2605  
3616  
2626


3617


2612

3625  
4625


3631  
2631  
2628  
3626  
3637  
7630 E B  
C  
3630  
6636 A4636 K  
2630  
4635  
3635 E B  
7635  
C  
2633  
A6633K  
2634  
3634  
A6635K  
3638









3139 123 5674.1




# LTI/CTI INTERFACE









## J FRONT INTERFACE






## A4 HERCULES



### A2 LINE + FRAME DEFLECTION






### A3 TUNER IF




## CONTROL





## A1 POWER SUPPLY




## A2 LINE + FRAME DEFLECTION




**B1** CRT




## A5 FEATURES & CONNECTIVITIES




## A9 FRONT CONTROL




## LINEARITY & PANORAMA




## 1212




## 12C BUS INTERCONNECTION DIAGRAM



## A5 FEATURES & CONNECTIONS




### A3 TUNER II




**A5**



## H LTI/CTI INTERFACE




**F1**



**F2** TUNER



**PIP MODULE (optional)**



## ERROR CODE LIST

	Error	Device	Error description	Crack item	Diagram
0	Not applicable	PC error	PC error	3411, 3422, 3413	A2
1	Not applicable	High beam (EB) protection (AS 00)	High beam (EB) protection (AS 00)	3404, 3445, 3404, 3445, 3412	A2
2	Not applicable	Vertical guard protection	Vertical guard protection	3466, 3461, 3462, 3463, 3464	A2
3	Not applicable	EB protection	EB protection	7604, 7605	A5
4	Not applicable	General PC error	General PC error	7700, 3247, 3242	A4
5	PC bus	PC bus while communicating with the PLC unit	PC bus while communicating with the PLC unit	3404, 3405	A5
6	24C-16	PC bus while communicating with the PLC unit	PC bus while communicating with the PLC unit	1400, 5601	A3
7	10000	Black current loop instability protection	Black current loop instability protection	7330, 3381, 3411	B1
11	100A/0.7A	PC error while communicating with I1 module	PC error while communicating with I1 module	7610	H
15	10A/2.781 mA	PC error while communicating with SS1 slave sound cooler	PC error while communicating with SS1 slave sound cooler	7200	A4
19	10A/200x	PC error while communicating with video camera I1 modules [C]	PC error while communicating with video camera I1 modules [C]	7500	A4
20	10A/200x				