

Fuelish Errors

• In my "Fuel Miser" article (October 1984), I'd like to correct some errors. On the schematic diagram, pin 2 of *IC1* should go directly to pin 6 of *IC1*, not to the common line as shown; and the *CR5* symbol should have the jogged bar of a zener diode. In the text on page 74, instructions should read: For gas systems, connect the jumper between points A and C. For oil systems, connect the jumper between Pins B and C.

Anthony Caristi
Waldwick, NJ