



NSX-DS8

U

SERVICE MANUAL

COMPACT DISC / STEREO
CASSETTE RECEIVER

BASIC TAPE MECHANISM : 2ZM-3MK2 PR7NM
BASIC CD MECHANISM : AZG-1 ZD3RNDM

- Replace this Service manual with "Revision Publishing" when it is issued.

aiwa

S/M Code No. 09-007-436-3T1

SIMPLE

DATA

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	AC-3		89-990-143-410	0E	WIRE,U24X0-14-5 F	USM	CX-NDS8
O	AC-3	C 0401	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0402	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0403	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	AC-3	C 0404	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	AC-3	C 0405	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0406	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0407	87-010-408-080	0E	CAP,E 47-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0408	87-010-408-080	0E	CAP,E 47-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0409	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
X	AC-3	C 0413	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	C 0414	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	AC-3	C 0421	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0422	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
X	AC-3	C 0423	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	AC-3	C 0424	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	AC-3	C 0425	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0426	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0427	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	AC-3	C 0428	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0431	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
X	AC-3	C 0432	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	AC-3	C 0451	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0452	87-010-378-080	0E	CAP,E 10-16 M 11L SME	USM	CX-NDS8
O	AC-3	C 0453	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	AC-3	C 0454	87-010-378-080	0E	CAP,E 10-16 M 11L SME	USM	CX-NDS8
O	AC-3	C 0489	87-010-402-080	0E	CAP,E 2.2-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0491	87-010-402-080	0E	CAP,E 2.2-50 M 11L SME	USM	CX-NDS8
O	AC-3	C 0492	87-010-402-080	0E	CAP,E 2.2-50 M 11L SME	USM	CX-NDS8
X	AC-3	CLP0401	87-A60-884-010	0E	PIN,DIA1 COATING-SHS	USM	CX-NDS8
O	AC-3	CNA0401	8A-NFG-651-010	-	CONN ASSY,10P ANF-G(BLUE)	USM	CX-NDS8
O	AC-3	CNA0402	8A-NFG-652-010	-	CONN ASSY,10P ANF-G(RED)	USM	CX-NDS8
S	AC-3	D 0401	87-A40-737-080	0E	ZENER,UZ2.2BSB	USM	CX-NDS8
S	AC-3	D 0402	87-A40-737-080	0E	ZENER,UZ2.2BSB	USM	CX-NDS8
X	AC-3	FB 0401	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
S	AC-3	IC 0401	87-A21-111-040	1C	C-IC,M62495FP	USM	CX-NDS8
S	AC-3	IC 0402	87-A21-111-040	1C	C-IC,M62495FP	USM	CX-NDS8
S	AC-3	IC 0403	87-070-391-040	1A	C-IC,BA4558F	USM	CX-NDS8
X	AC-3	JR 0402	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	JR 0403	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	AC-3	JR 0404	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	JR 0407	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	JR 0473	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
S	AC-3	Q 0401	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
S	AC-3	Q 0402	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
S	AC-3	Q 0403	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	AC-3	Q 0404	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
S	AC-3	Q 0410	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	AC-3	Q 0451	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
X	AC-3	R 0401	88-118-393-080	0E	C-RES,S 39K-1/10W J	USM	CX-NDS8
X	AC-3	R 0402	88-118-393-080	0E	C-RES,S 39K-1/10W J	USM	CX-NDS8
X	AC-3	R 0403	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	AC-3	R 0404	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	AC-3	R 0405	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	AC-3	R 0406	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	AC-3	R 0407	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AC-3	R 0408	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AC-3	R 0409	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AC-3	R 0410	88-121-822-080	0E	RES,8.2K-1/8W J	USM	CX-NDS8
X	AC-3	R 0411	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
X	AC-3	R 0415	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	R 0416	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	R 0421	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AC-3	R 0422	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AC-3	R 0423	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	AC-3	R 0424	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	AC-3	R 0425	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	AC-3	R 0426	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	AC-3	R 0427	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	AC-3	R 0429	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME	
X	AC-3	R	0430	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	AC-3	R	0432	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
O	AC-3	R	0435	87-A00-373-050	0E	RES,M/F 270-1W J VTP	USM	CX-NDS8
O	AC-3	R	0436	87-A00-373-050	0E	RES,M/F 270-1W J VTP	USM	CX-NDS8
X	AC-3	R	0437	88-128-221-080	0E	C-RES, 220-1/8W J	USM	CX-NDS8
X	AC-3	R	0438	88-128-221-080	0E	C-RES, 220-1/8W J	USM	CX-NDS8
X	AC-3	R	0439	88-128-221-080	0E	C-RES, 220-1/8W J	USM	CX-NDS8
X	AC-3	R	0440	88-128-221-080	0E	C-RES, 220-1/8W J	USM	CX-NDS8
X	AC-3	R	0441	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	AC-3	R	0442	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	AC-3	R	0451	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AC-3	R	0452	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AC-3	R	0453	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AC-3	R	0454	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AC-3	R	0455	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AC-3	R	0456	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AC-3	R	0457	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AC-3	R	0458	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AC-3	R	0459	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AC-3	R	0460	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AC-3	R	0473	88-121-222-080	0E	RES,2.2K-1/8W J	USM	CX-NDS8
X	AC-3	R	0474	88-121-222-080	0E	RES,2.2K-1/8W J	USM	CX-NDS8
X	AC-3	R	0475	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AC-3	R	0476	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AC-3	R	0480	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AC-3	R	0481	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AC-3	R	0482	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	AC-3	W	0401	8Z-NFD-646-010	0E	WIRE,FASTON-1P-400 MM	USM	CX-NDS8
O	ACCESSORY			87-006-225-010	1D	ANT,LOOP ANT NC2	USM	CX-NDS8
O	ACCESSORY			87-043-115-010	1A	FEEDER-ANT,FM	USM	CX-NDS8
O	ACCESSORY			8Z-NFD-702-010	2A	RC UNIT,RC- ZAS22	USM	CX-NDS8
X	AMP 1F	*		8A-NF6-650-210	1C	PWB,AMP 1F 2M	USM	CX-NDS8
O	AMP 1F	C	0101	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0102	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0103	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0104	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0107	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0108	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0111	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0112	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0113	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0114	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0115	87-010-866-080	0E	CAP,E 10-63 M VX	USM	CX-NDS8
O	AMP 1F	C	0116	87-010-866-080	0E	CAP,E 10-63 M VX	USM	CX-NDS8
O	AMP 1F	C	0119	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0120	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0133	87-010-190-080	0E	C-CAP,S 0.01-50 Z F C2012	USM	CX-NDS8
O	AMP 1F	C	0153	87-010-188-080	0E	C-CAP,S 6800P-50 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0201	87-A12-369-080	0E	CAP,M 0.027-100 J CP	USM	CX-NDS8
O	AMP 1F	C	0202	87-A12-369-080	0E	CAP,M 0.027-100 J CP	USM	CX-NDS8
O	AMP 1F	C	0203	87-A12-369-080	0E	CAP,M 0.027-100 J CP	USM	CX-NDS8
O	AMP 1F	C	0204	87-A12-369-080	0E	CAP,M 0.027-100 J CP	USM	CX-NDS8
O	AMP 1F	C	0205	87-010-180-080	0E	C-CAP,S 1500P-50 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0206	87-010-180-080	0E	C-CAP,S 1500P-50 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0207	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0208	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0209	87-010-187-080	0E	C-CAP,S 5600P-50 K B	USM	CX-NDS8
O	AMP 1F	C	0210	87-010-187-080	0E	C-CAP,S 5600P-50 K B	USM	CX-NDS8
O	AMP 1F	C	0211	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0212	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0215	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0216	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	AMP 1F	C	0217	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0218	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0221	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0222	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	AMP 1F	C	0223	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0224	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	AMP 1F	C	0251	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8
O	AMP 1F	C	0252	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT	NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
	O AMP	1F	C 0253	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
	O AMP	1F	C 0254	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
	O AMP	1F	C 0401	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
!	O AMP	1F	CN 0101	87-A61-011-010	0E	CONN,13P H BLK TAC-L13P-A3	USM	CX-NDS8
!	O AMP	1F	CN 0102	87-A61-011-010	0E	CONN,13P H BLK TAC-L13P-A3	USM	CX-NDS8
!	O AMP	1F	CN 0105	87-099-198-010	0E	CONN,10P V BLK 6216	USM	CX-NDS8
	O AMP	1F	CNA0101	8A-NF6-645-010	1B	CONN ASSY,5P TID-A(530)	USM	CX-NDS8
!	O AMP	1F	CNA0103	8A-NF8-655-010	1A	CONN ASSY,7P TID-A(250)	USM	CX-NDS8
	S AMP	1F	D 0101	87-A40-269-080	0E	C-DIODE,MC2836	USM	CX-NDS8
	S AMP	1F	D 0102	87-A40-270-080	0E	C-DIODE,MC2838	USM	CX-NDS8
	S AMP	1F	D 0103	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8
	S AMP	1F	D 0150	87-A40-270-080	0E	C-DIODE,MC2838	USM	CX-NDS8
	S AMP	1F	D 0201	87-A40-269-080	0E	C-DIODE,MC2836	USM	CX-NDS8
	S AMP	1F	D 0203	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8
	S AMP	1F	D 0204	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
	S AMP	1F	D 0401	87-A40-270-080	0E	C-DIODE,MC2838	USM	CX-NDS8
	S AMP	1F	D 0402	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
	S AMP	1F	D 0403	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
	S AMP	1F	IC 0101	87-A21-418-010	2M	IC,STK490-340	USM	CX-NDS8
!	S AMP	1F	IC 0201	87-A21-397-010	2A	IC,STK490-070	USM	CX-NDS8
	O AMP	1F	J 0202	87-A61-158-010	1A	JACK,PIN 2P R/W/BL H(SEPA) KM	USM	CX-NDS8
	X AMP	1F	JR 0101	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0103	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0104	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0106	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0113	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0115	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
	X AMP	1F	JR 0201	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
	X AMP	1F	JR 0203	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0204	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0205	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0206	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0207	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
	X AMP	1F	JR 0208	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	X AMP	1F	JR 0401	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
	O AMP	1F	L 0251	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8
	O AMP	1F	L 0252	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8
	S AMP	1F	Q 0101	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
	S AMP	1F	Q 0102	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
	S AMP	1F	Q 0150	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
	S AMP	1F	Q 0151	87-A30-106-040	0E	C-TR,CMBT5551	USM	CX-NDS8
	S AMP	1F	Q 0201	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
	S AMP	1F	Q 0202	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
	S AMP	1F	Q 0203	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
	S AMP	1F	Q 0204	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
	S AMP	1F	Q 0401	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
	S AMP	1F	Q 0402	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
	X AMP	1F	R 0101	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0102	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0103	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0104	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0105	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0106	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0109	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0110	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0111	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0112	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0121	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
	X AMP	1F	R 0123	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
	X AMP	1F	R 0125	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
	X AMP	1F	R 0126	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
	O AMP	1F	R 0129	87-A00-262-080	0E	RES,M/F 0.15-2W J	USM	CX-NDS8
	O AMP	1F	R 0130	87-A00-262-080	0E	RES,M/F 0.15-2W J	USM	CX-NDS8
	X AMP	1F	R 0133	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0134	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0135	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0136	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0137	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0138	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
	X AMP	1F	R 0141	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT	NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	AMP	1F	R 0142	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0143	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0144	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0145	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0146	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0150	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0151	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0152	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0153	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0154	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0171	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0172	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0201	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0202	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0205	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0206	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0207	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0208	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0209	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0210	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0211	88-118-393-080	0E	C-RES,S 39K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0212	88-118-393-080	0E	C-RES,S 39K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0213	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0214	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0215	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0216	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0217	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0218	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0219	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0220	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0221	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0222	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0223	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0224	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0227	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0228	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
O	AMP	1F	R 0231	87-A00-258-080	0E	RES,M/F 0.22-1W J	USM	CX-NDS8
O	AMP	1F	R 0232	87-A00-258-080	0E	RES,M/F 0.22-1W J	USM	CX-NDS8
X	AMP	1F	R 0233	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0234	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0235	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0236	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0237	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0238	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0239	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0240	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0241	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0242	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0245	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0246	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0251	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	AMP	1F	R 0252	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	AMP	1F	R 0253	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0254	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0255	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0256	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0260	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0261	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0262	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0264	88-118-271-080	0E	C-RES,S 270-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0271	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0272	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0304	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0305	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0306	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0309	88-128-103-080	0E	C-RES, 10K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0310	88-128-103-080	0E	C-RES, 10K-1/8W J	USM	CX-NDS8
X	AMP	1F	R 0401	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0402	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	AMP	1F	R 0403	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT	NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME	
X	AMP	1F	R 0404	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8	
X	AMP	1F	R 0405	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8	
!	O	AMP	1F	WH 0101	87-A90-459-010	0E	HLDLDR,WIRE 2.5-5P	USM	CX-NDS8
!	O	AMP	1F	WH 0102	87-A90-460-010	0E	HLDLDR,WIRE 2.5-7P	USM	CX-NDS8
X	AMP	2F	*	8A-NF6-655-210	1B	PWB,AMP 2M P-LOGIC	USM	CX-NDS8	
O	AMP	2F	C 0101	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8	
O	AMP	2F	C 0102	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8	
O	AMP	2F	C 0103	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0104	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0107	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0108	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0111	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8	
O	AMP	2F	C 0112	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8	
O	AMP	2F	C 0113	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0114	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0115	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0116	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0121	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0122	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0151	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0152	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0153	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0154	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0155	87-010-190-080	0E	C-CAP,S 0.01-50 Z F C2012	USM	CX-NDS8	
O	AMP	2F	C 0156	87-010-190-080	0E	C-CAP,S 0.01-50 Z F C2012	USM	CX-NDS8	
O	AMP	2F	C 0160	87-010-190-080	0E	C-CAP,S 0.01-50 Z F C2012	USM	CX-NDS8	
O	AMP	2F	C 0161	87-010-188-080	0E	C-CAP,S 6800P-50 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0201	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8	
O	AMP	2F	C 0202	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0203	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8	
O	AMP	2F	C 0204	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0205	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0206	87-A10-946-080	0E	C-CAP,S 220P-100 J CH	USM	CX-NDS8	
O	AMP	2F	C 0208	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0209	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0210	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8	
O	AMP	2F	C 0211	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0212	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8	
O	AMP	2F	C 0251	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0252	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	AMP	2F	C 0253	87-010-190-080	0E	C-CAP,S 0.01-50 Z F C2012	USM	CX-NDS8	
!	O	AMP	2F	CN 0101	87-A61-109-010	0E	CONN,7P V TID-A	USM	CX-NDS8
!	O	AMP	2F	CN 0102	87-099-198-010	0E	CONN,10P V BLK 6216	USM	CX-NDS8
S	AMP	2F	D 0101	87-A40-269-080	0E	C-DIODE,MC2836	USM	CX-NDS8	
S	AMP	2F	D 0103	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8	
S	AMP	2F	D 0160	87-A40-270-080	0E	C-DIODE,MC2838	USM	CX-NDS8	
S	AMP	2F	D 0201	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0202	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0203	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0204	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0205	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0207	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0208	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0209	87-A40-535-080	0E	DIODE,1N5393-GOODARK	USM	CX-NDS8	
S	AMP	2F	D 0210	87-A40-535-080	0E	DIODE,1N5393-GOODARK	USM	CX-NDS8	
S	AMP	2F	D 0211	87-A40-754-080	0E	ZENER,UZ6.8BSC	USM	CX-NDS8	
S	AMP	2F	D 0212	87-A40-754-080	0E	ZENER,UZ6.8BSC	USM	CX-NDS8	
S	AMP	2F	D 0214	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8	
S	AMP	2F	D 0216	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	AMP	2F	D 0218	87-A40-535-080	0E	DIODE,1N5393-GOODARK	USM	CX-NDS8	
S	AMP	2F	D 0219	87-A40-535-080	0E	DIODE,1N5393-GOODARK	USM	CX-NDS8	
!	S	AMP	2F	IC 0101	87-A21-397-010	2A	IC,STK490-070	USM	CX-NDS8
O	AMP	2F	J 0101	87-A61-485-010	0E	JACK,PIN 4P RWBO TC58 118-14	USM	CX-NDS8	
X	AMP	2F	JR 0102	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	AMP	2F	JR 0103	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	AMP	2F	JR 0104	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	AMP	2F	JR 0105	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	AMP	2F	JR 0107	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	AMP	2F	JR 0108	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
O	AMP	2F	L 0151	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8	

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT	NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	AMP	2F	L 0152	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8
O	AMP	2F	L 0251	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8
S	AMP	2F	Q 0101	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
S	AMP	2F	Q 0102	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
S	AMP	2F	Q 0160	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
S	AMP	2F	Q 0161	87-A30-106-040	0E	C-TR,CMBT5551	USM	CX-NDS8
S	AMP	2F	Q 0201	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	AMP	2F	Q 0202	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	AMP	2F	Q 0203	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	AMP	2F	Q 0204	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	AMP	2F	Q 0206	87-A30-190-080	0E	TR,CC5551	USM	CX-NDS8
S	AMP	2F	Q 0207	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	AMP	2F	Q 0208	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	AMP	2F	Q 0209	87-A30-256-010	1A	TR,2SD1933	USM	CX-NDS8
S	AMP	2F	Q 0210	87-A30-255-010	1A	TR,2SB1342	USM	CX-NDS8
S	AMP	2F	Q 0211	87-A30-256-010	1A	TR,2SD1933	USM	CX-NDS8
S	AMP	2F	Q 0212	87-A30-255-010	1A	TR,2SB1342	USM	CX-NDS8
S	AMP	2F	Q 0213	87-A30-107-070	0E	C-TR,CMBT5401	USM	CX-NDS8
S	AMP	2F	Q 0214	87-A30-074-080	0E	C-TR,RT1P 141C	USM	CX-NDS8
S	AMP	2F	Q 0215	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	AMP	2F	Q 0217	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
X	AMP	2F	R 0101	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0102	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0103	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0104	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0105	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0106	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0109	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0110	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0111	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0112	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0121	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0123	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0125	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0126	88-128-332-080	0E	C-RES, 3.3K-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0127	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0128	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
O	AMP	2F	R 0131	87-A00-258-080	0E	RES,M/F 0.22-1W J	USM	CX-NDS8
O	AMP	2F	R 0132	87-A00-258-080	0E	RES,M/F 0.22-1W J	USM	CX-NDS8
X	AMP	2F	R 0133	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0134	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0135	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0136	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0137	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0138	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0139	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0140	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0141	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0142	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0145	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0146	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0151	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	AMP	2F	R 0152	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	AMP	2F	R 0153	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0154	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0155	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0156	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	AMP	2F	R 0160	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0161	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0162	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0163	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0164	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0201	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0202	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0203	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0204	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0205	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0206	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0207	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP	2F	R 0208	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	AMP 2F	R 0209	88-128-222-080	0E	C-RES, 2.2K-1/8W J	USM	CX-NDS8
X	AMP 2F	R 0210	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0211	88-128-222-080	0E	C-RES, 2.2K-1/8W J	USM	CX-NDS8
X	AMP 2F	R 0212	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0213	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0214	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0215	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0216	88-118-390-080	0E	C-RES,S 39-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0217	88-118-331-080	0E	C-RES,S 330-1/10W J	USM	CX-NDS8
O	AMP 2F	R 0218	87-A00-258-080	0E	RES,M/F 0.22-1W J	USM	CX-NDS8
X	AMP 2F	R 0219	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0220	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0221	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0222	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0223	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0224	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0226	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0227	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0228	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0229	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0231	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0232	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0233	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0235	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0236	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0237	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0238	88-118-271-080	0E	C-RES,S 270-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0239	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0251	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	AMP 2F	R 0252	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	AMP 2F	R 0253	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
O	AMP 2F	TH 0201	87-A91-042-080	0E	C-THMS,100K 55001	USM	CX-NDS8
O	APPEARANCE		8A-NF6-003-010	1C	CABI,BOTTOM	USM	CX-NDS8
O	APPEARANCE		8A-NF6-005-010	1D	PANEL, TOP	USM	CX-NDS8
O	APPEARANCE		8A-NF6-006-110	1D	BOX,CASS 1	USM	CX-NDS8
O	APPEARANCE		8A-NF6-007-110	1D	BOX,CASS 2	USM	CX-NDS8
O	APPEARANCE		8A-NF6-008-010	1C	PANEL, TRAY	USM	CX-NDS8
O	APPEARANCE		8A-NF6-009-110	1B	PANEL, CD	USM	CX-NDS8
O	APPEARANCE		8A-NF6-010-010	1D	PANEL, DIRECT	USM	CX-NDS8
O	APPEARANCE		8A-NF6-018-010	0E	WINDOW,CASS 1	USM	CX-NDS8
O	APPEARANCE		8A-NF6-019-010	0E	WINDOW,CASS 2	USM	CX-NDS8
O	APPEARANCE		8A-NF6-041-010	1A	RING,VOL	USM	CX-NDS8
O	APPEARANCE		8A-NF6-058-010	2M	CABI,STEEL HR	USM	CX-NDS8
O	APPEARANCE		8A-NFG-002-010	1B	WINDOW, DISP U	USM	CX-NDS8
O	APPEARANCE		8A-NFG-008-010	-	PANEL, FR U	USM	CX-NDS8
O	APPEARANCE		8A-NFG-010-010	-	COVER, REAR USM	USM	CX-NDS8
O	APPEARANCE		8A-NFG-011-010	1C	PANEL, REAR USM	USM	CX-NDS8
O	APPEARANCE	*	8A-NFG-001-010	1H	CABI, FR U	USM	CX-NDS8
O	CD		84-ZG1-245-210	0E	CAP, OPTICAL	USM	CX-NDS8
X	CD		M8-AZG-19P-230	-	AZG-1 ZD3RNDM	USM	CX-NDS8
O	DOLBY DIGITAL		87-067-579-010	0E	BVT2+3-8 W/O SL0T	USM	CX-NDS8
X	DOLBY DIGITAL		88-AR1-219-010	0E	HT-SINK, TR	USM	CX-NDS8
X	DOLBY DIGITAL		89-990-243-410	0E	WIRE,U24X0-24-5	USM	CX-NDS8
X	DOLBY DIGITAL		8Z-NFD-630-210	1C	PWB, AC-3	USM	CX-NDS8
O	DOLBY DIGITAL	C 0101	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0102	87-010-374-080	0E	CAP,E 47-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0103	87-010-314-080	0E	C-CAP,S 22P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0104	87-010-313-080	0E	C-CAP,S 18P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0105	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0106	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0107	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0108	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0109	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0110	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0111	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0112	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0113	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0114	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0115	87-010-374-080	0E	CAP,E 47-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0116	87-012-140-080	0E	C-CAP,S 470P-50 J CH	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	DOLBY DIGITAL	C 0117	87-010-198-080	0E	C-CAP,S 0.022-25 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0118	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0119	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0120	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0121	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0122	87-010-311-080	0E	C-CAP,S 12P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0123	87-010-311-080	0E	C-CAP,S 12P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0124	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0125	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0126	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0127	87-010-555-040	0E	CAP,E 100-10 M 5L SRE	USM	CX-NDS8
O	DOLBY DIGITAL	C 0128	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0129	87-010-384-080	0E	CAP,E 100-25 M 11L SME	USM	CX-NDS8
X	DOLBY DIGITAL	C 0130	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
O	DOLBY DIGITAL	C 0131	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0132	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0135	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0136	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0140	87-010-552-040	0E	CAP,E 22-16 M 5L SRE	USM	CX-NDS8
O	DOLBY DIGITAL	C 0141	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0143	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0144	87-010-312-080	0E	C-CAP,S 15P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0145	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0146	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0147	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0148	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0149	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0150	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0151	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0152	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0153	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0154	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0155	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0157	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0158	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0159	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0160	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0161	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0162	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0163	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0164	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0165	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0166	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0167	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0169	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0170	87-012-154-080	0E	C-CAP,S 150P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0171	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0172	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0173	87-018-209-080	0E	CAP,TC U 0.1-50 Z F UP050	USM	CX-NDS8
O	DOLBY DIGITAL	C 0174	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0175	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0177	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0178	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0179	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0180	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0181	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0182	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0183	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0184	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0185	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0186	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0187	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0188	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0189	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0190	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0191	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0192	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0193	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0194	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0195	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	DOLBY DIGITAL	C 0196	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0197	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0198	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0199	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0201	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0202	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0203	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0204	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0205	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0206	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0207	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0208	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0209	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0210	87-010-154-080	0E	C-CAP,S 10P-50 D CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0211	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0212	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0213	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0214	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0215	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0216	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0217	87-A10-793-080	0E	C-CAP,S 0.12-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0218	87-A10-793-080	0E	C-CAP,S 0.12-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0219	87-010-993-080	0E	C-CAP,S 0.056-25 K B MK212	USM	CX-NDS8
O	DOLBY DIGITAL	C 0220	87-A10-369-080	0E	C-CAP,S 0.47-16 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0222	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0224	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0225	87-012-155-080	0E	C-CAP,S 180P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0226	87-012-155-080	0E	C-CAP,S 180P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0227	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0228	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0230	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0232	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0236	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0237	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0238	87-010-314-080	0E	C-CAP,S 22P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0239	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0240	87-010-314-080	0E	C-CAP,S 22P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0241	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0242	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0243	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0260	87-010-378-080	0E	CAP,E 10-16 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0261	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0270	87-012-155-080	0E	C-CAP,S 180P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0301	87-012-393-080	0E	C-CAP,S 0.22-16 K W5R CM/CB	USM	CX-NDS8
O	DOLBY DIGITAL	C 0302	87-012-393-080	0E	C-CAP,S 0.22-16 K W5R CM/CB	USM	CX-NDS8
O	DOLBY DIGITAL	C 0303	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0304	87-012-393-080	0E	C-CAP,S 0.22-16 K W5R CM/CB	USM	CX-NDS8
O	DOLBY DIGITAL	C 0305	87-010-184-080	0E	C-CAP,S 3300P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0306	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0307	87-016-669-080	0E	C-CAP,S 0.1-25 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0308	87-016-669-080	0E	C-CAP,S 0.1-25 K B	USM	CX-NDS8
O	DOLBY DIGITAL	C 0309	87-010-184-080	0E	C-CAP,S 3300P-50 K B C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0310	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0311	87-012-393-080	0E	C-CAP,S 0.22-16 K W5R CM/CB	USM	CX-NDS8
O	DOLBY DIGITAL	C 0312	87-010-374-080	0E	CAP,E 47-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0313	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0315	87-010-374-080	0E	CAP,E 47-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0316	87-010-374-080	0E	CAP,E 47-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0317	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0318	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0319	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0320	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0321	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0401	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DOLBY DIGITAL	C 0402	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0403	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	DOLBY DIGITAL	C 0405	87-018-147-080	0E	CAP,TC U 10P-50 J CH UP050	USM	CX-NDS8
O	DOLBY DIGITAL	C 0502	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0506	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	DOLBY DIGITAL	C 0508	87-018-119-080	0E	CAP,TC U 100P-50 K B UP050	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	DOLBY DIGITAL	C 0511	87-018-113-080	0E	CAP,TC U 33P-50 J SL UP050	USM	CX-NDS8
O	DOLBY DIGITAL	C 0512	87-A11-132-080	0E	CAP,TC U 0.01-50 K B	USM	CX-NDS8
!	DOLBY DIGITAL	CN 0101	87-A60-057-010	0E	CONN,11P V 9604S-11C	USM	CX-NDS8
O	DOLBY DIGITAL	CN 0102	87-A60-627-010	0E	CONN,10P V 2MM JMT	USM	CX-NDS8
O	DOLBY DIGITAL	CN 0105	87-A60-627-010	0E	CONN,10P V 2MM JMT	USM	CX-NDS8
O	DOLBY DIGITAL	CNA0101	8A-NFG-650-010	1A	CONN ASSY,6P ANF-G	USM	CX-NDS8
S	DOLBY DIGITAL	D 0101	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	DOLBY DIGITAL	D 0301	87-017-931-080	0E	ZENER,MTZJ5.6B	USM	CX-NDS8
S	DOLBY DIGITAL	D 0401	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	DOLBY DIGITAL	D 0402	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	DOLBY DIGITAL	D 0403	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	DOLBY DIGITAL	D 0404	87-A40-348-080	0E	ZENER,MTZJ3.3A	USM	CX-NDS8
S	DOLBY DIGITAL	D 0410	87-A40-737-080	0E	ZENER,UZ2.2BSE	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0102	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0103	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0104	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0105	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0106	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0107	87-008-474-080	0E	F-BEAD, BL02RN1-R62T2 EMI	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0108	87-008-474-080	0E	F-BEAD, BL02RN1-R62T2 EMI	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0109	87-008-474-080	0E	F-BEAD, BL02RN1-R62T2 EMI	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0110	87-003-223-080	0E	F-BEAD, BL02RN2	USM	CX-NDS8
O	DOLBY DIGITAL	FB 0112	87-003-223-080	0E	F-BEAD, BL02RN2	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0101	87-A20-823-010	2D	C-IC,YSS248	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0102	87-A20-824-010	2C	C-IC,CS4226	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0103	87-020-903-010	1B	IC,NJM7805FA	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0105	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0106	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0107	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0108	87-020-784-080	1B	C-IC,TC4053BF	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0109	87-020-784-080	1B	C-IC,TC4053BF	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0110	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0111	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0112	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0113	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0114	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0117	87-A21-018-040	1H	C-IC,M65849BFP631D	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0118	87-001-604-080	1A	C-IC,TC74HC004M	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0119	87-020-784-080	1B	C-IC,TC4053BF	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0120	87-017-022-080	1A	C-IC,NJM2068M-D(T1)	USM	CX-NDS8
S	DOLBY DIGITAL	IC 0121	87-002-298-080	1A	C-IC,TC74HC00AF	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0103	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0104	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0106	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0107	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0108	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0109	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0110	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0111	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0112	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0113	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0114	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0115	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0116	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0117	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0119	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0120	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0121	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0123	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0124	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0125	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0126	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0127	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0128	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0129	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0131	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0132	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0133	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0134	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0135	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	DOLBY DIGITAL	JR 0136	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0137	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0138	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0139	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0140	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0141	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0142	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0143	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0144	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0145	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0146	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0147	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0148	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0149	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0150	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0151	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0152	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0153	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0154	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0155	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0156	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0160	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0161	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0165	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0166	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0167	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0168	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0170	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0175	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	JR 0181	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	DOLBY DIGITAL	L 0102	87-A50-095-010	1A	COIL,68UH RCR875D	USM	CX-NDS8
O	DOLBY DIGITAL	L 0104	87-008-501-080	0E	FLTR, DSS306-55	USM	CX-NDS8
O	DOLBY DIGITAL	L 0106	87-003-097-080	0E	COIL,1.0UH K LAL02	USM	CX-NDS8
X	DOLBY DIGITAL	P 0001	86-NFZ-222-010	0E	PIN,DIAL-5.6	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0101	87-A30-071-080	0E	C-TR,RT1N 144C	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0102	87-A30-071-080	0E	C-TR,RT1N 144C	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0103	87-A30-071-080	0E	C-TR,RT1N 144C	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0105	87-A30-071-080	0E	C-TR,RT1N 144C	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0106	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0107	87-A30-257-080	0E	C-TR,2SD1306E	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0401	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0402	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0403	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0404	87-026-608-080	0E	C-TR,DTC123JK	USM	CX-NDS8
S	DOLBY DIGITAL	Q 0405	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
X	DOLBY DIGITAL	R 0101	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0102	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0103	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0104	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0105	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0106	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0107	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0108	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0109	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0110	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0111	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0112	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0113	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0114	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0115	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0116	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0117	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0118	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0119	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0120	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0121	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0122	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0123	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0124	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0125	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	DOLBY DIGITAL	R 0126	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0127	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0128	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0129	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0130	88-121-472-080	0E	RES,4.7K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0133	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0138	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0139	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0140	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0143	88-118-221-080	0E	C-RES,S 220-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0144	88-118-221-080	0E	C-RES,S 220-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0145	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0146	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0147	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0148	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0149	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0150	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0151	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0153	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0154	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0155	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0156	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0157	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0158	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0159	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0160	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0161	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0162	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0163	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0164	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0165	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0166	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0167	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0168	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0169	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0170	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0171	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0172	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0173	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0175	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0176	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0177	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0178	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0179	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0180	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0181	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0182	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0183	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0184	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0185	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0186	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0187	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0188	88-121-124-080	0E	RES,120K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0189	88-121-124-080	0E	RES,120K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0190	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0191	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0192	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0193	88-118-393-080	0E	C-RES,S 39K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0194	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0195	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0196	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0197	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0199	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0200	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0201	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0202	88-121-152-080	0E	RES,1.5K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0203	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0204	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0205	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0206	88-121-124-080	0E	RES,120K-1/8W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	DOLBY DIGITAL	R 0207	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0208	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0209	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0210	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0211	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0212	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0213	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0214	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0215	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0216	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0217	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0218	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0219	88-128-152-080	0E	C-RES, 1.5K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0220	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0221	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0222	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0223	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0224	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0225	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0226	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0227	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0228	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0229	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0230	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0231	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0233	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0234	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0235	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0236	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0237	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0238	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0239	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0240	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0243	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0244	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0245	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0246	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0249	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0250	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0251	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0252	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0253	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0256	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0257	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0258	88-128-153-080	0E	C-RES, 15K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0259	88-121-153-080	0E	RES,15K-1/8W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0267	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0268	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0269	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0270	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0271	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0272	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0273	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0275	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0276	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0277	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	DOLBY DIGITAL	R 0278	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	DOLBY DIGITAL	R 0279	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0287	88-118-470-080	0E	C-RES,S 47-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0288	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0289	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0291	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0292	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0293	88-118-683-080	0E	C-RES,S 68K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0294	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0295	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0296	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0301	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0302	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0303	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	DOLBY DIGITAL	R 0304	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0305	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0306	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	DOLBY DIGITAL	R 0307	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0308	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0309	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0310	88-140-121-080	0E	RES,120-1/2W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0401	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0402	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0403	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0404	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0405	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0406	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0407	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0408	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0409	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0410	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	R 0411	88-118-100-080	0E	C-RES,S 10-1/10W J	USM	CX-NDS8
X	DOLBY DIGITAL	W 0403	87-A60-884-010	0E	PIN,DIAL COATING-SHS	USM	CX-NDS8
X	DOLBY DIGITAL	W 0405	87-A60-884-010	0E	PIN,DIAL COATING-SHS	USM	CX-NDS8
O	DOLBY DIGITAL	X 0101	87-A70-116-010	1B	VIB,XTAL 10.00MHZ	USM	CX-NDS8
O	DOLBY DIGITAL	X 0102	87-A70-115-010	1B	VIB,XTAL 12.288MHZ	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0531	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0532	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0533	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0534	87-012-156-080	0E	C-CAP,S 220P-50 J CH GRM	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0535	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0536	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	DSP/ECHO(MIC MIX)	C 0541	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	CLP0501	87-A60-884-010	0E	PIN,DIAL COATING-SHS	USM	CX-NDS8
S	DSP/ECHO(MIC MIX)	Q 0531	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	DSP/ECHO(MIC MIX)	Q 0532	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0531	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0532	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0533	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0534	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0535	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0536	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	DSP/ECHO(MIC MIX)	R 0537	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
O	E-GEQ	C 0202	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	E-GEQ	C 0203	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	E-GEQ	C 0205	87-010-314-080	0E	C-CAP,S 22P-50 J CH GRM	USM	CX-NDS8
O	E-GEQ	C 0206	87-010-182-080	0E	C-CAP,S 2200P-50 K B C2012	USM	CX-NDS8
O	E-GEQ	CN 0201	87-A60-623-010	0E	CONN,6P V 2MM JMT	USM	CX-NDS8
!	S E-GEQ	IC 0201	87-A20-870-010	1F	IC,GP1F37R	USM	CX-NDS8
!	O E-GEQ	J 0201	87-A60-573-010	1A	JACK,PIN 1P ORN	USM	CX-NDS8
X	E-GEQ	JR 0205	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	E-GEQ	L 0201	87-005-274-080	0E	COLL,68UH K LAL03	USM	CX-NDS8
O	E-GEQ	L 0202	87-008-501-080	0E	FLTR, DSS306-55	USM	CX-NDS8
X	E-GEQ	R 0201	88-118-820-080	0E	C-RES,S 82-1/10W J	USM	CX-NDS8
X	E-GEQ	R 0202	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	E-GEQ	R 0204	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	ELECTRICAL		80-XV1-218-010	0E	CUSH-S,PWB	USM	CX-NDS8
!	X ELECTRICAL		87-069-033-010	0E	CABLE,TIE	USM	CX-NDS8
!	O ELECTRICAL		87-085-189-010	0E	BUSHING,AC CORD(U) CM-22C	USM	CX-NDS8
X	ELECTRICAL		87-098-335-010	0E	LBL,REPLACEMENT	USM	CX-NDS8
!	X ELECTRICAL		87-098-374-010	0E	LBL,FUSE 10A 125V	USM	CX-NDS8
O	ELECTRICAL		87-A91-832-010	-	FAN,DSB0812H(DELTA) -400MM	USM	CX-NDS8
O	ELECTRICAL		88-904-281-110	0E	FF-CABLE,4P 1.25 280MM	USM	CX-NDS8
O	ELECTRICAL		88-906-621-110	1A	FF-CABLE,6P 1.25 620MM	USM	CX-NDS8
O	ELECTRICAL		88-907-421-110	0E	FF-CABLE,7P 1.25 420MM	USM	CX-NDS8
O	ELECTRICAL		88-910-151-110	0E	FF-CABLE, 10P 1.25 150MM	USM	CX-NDS8
O	ELECTRICAL		88-911-291-110	0E	FF-CABLE,11P 1.25 290MM	USM	CX-NDS8
O	ELECTRICAL		88-913-521-110	1A	FF-CABLE,13P 1.25 520MM	USM	CX-NDS8
O	ELECTRICAL		88-915-111-110	0E	FF-CABLE,15P 1.25	USM	CX-NDS8
X	ELECTRICAL		8Z-NF5-613-010	0E	WIRE ASSY,150 BLACK 24	USM	CX-NDS8
X	ELECTRICAL	*	8Z-NB6-230-010	0E	PLATE,SHLD RF S	USM	CX-NDS8
!	O ELECTRICAL	PT 0001	8A-NFG-621-010	-	PT,U EI96-75 ANF-G	USM	CX-NDS8
!	O ELECTRICAL	W 0001	87-A80-110-010	1B	AC CORD ASSY,U SPT-2W	USM	CX-NDS8
O	FLTR	C 0104	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME		
O	FLTR	C	0105	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8	
O	FLTR	C	0111	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0112	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0113	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0114	87-010-545-080	0E	CAP,E 0.22-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0115	87-010-546-080	0E	CAP,E 0.33-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0116	87-010-546-080	0E	CAP,E 0.33-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0121	87-010-546-080	0E	CAP,E 0.33-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0122	87-010-546-080	0E	CAP,E 0.33-50 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0152	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8	
O	FLTR	C	0171	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	FLTR	C	0172	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	FLTR	C	0173	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
O	FLTR	C	0174	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8	
!	O	FLTR	CN	0101	87-A60-996-010	0E	CONN,13P V BLK TAC-L13X-A3	USM	CX-NDS8
!	O	FLTR	J	0102	87-A60-238-010	1A	TERMINAL,SP 4P (MSC)	USM	CX-NDS8
O	FLTR	J	0103	87-A61-481-010	-	JACK,DIAG.3 BLK ST W/SW MSC16B	USM	CX-NDS8	
X	FLTR	JR	0101	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	FLTR	JR	0102	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8	
X	FLTR	JR	0106	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	FLTR	JR	0107	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	FLTR	JR	0109	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
X	FLTR	JR	0110	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8	
O	FLTR	L	0101	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8	
O	FLTR	L	0102	87-A50-610-010	0E	COIL,1UH K(MDEC)	USM	CX-NDS8	
S	FLTR	Q	0101	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0102	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0103	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0104	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0105	87-A30-269-040	0E	C-FET,2SJ461-T1	USM	CX-NDS8	
S	FLTR	Q	0106	87-A30-269-040	0E	C-FET,2SJ461-T1	USM	CX-NDS8	
S	FLTR	Q	0107	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0108	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0109	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0110	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
S	FLTR	Q	0111	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8	
S	FLTR	Q	0112	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8	
S	FLTR	Q	0113	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8	
S	FLTR	Q	0114	87-A30-221-040	0E	C-TR,DTA114WK	USM	CX-NDS8	
S	FLTR	Q	0115	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8	
X	FLTR	R	0101	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0102	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0105	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0106	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0107	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0108	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0109	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0110	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0111	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0112	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0115	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0116	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0117	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8	
X	FLTR	R	0118	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8	
X	FLTR	R	0121	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0122	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0123	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0124	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0125	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0126	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0127	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0128	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8	
X	FLTR	R	0129	88-121-562-080	0E	RES,5.6K-1/8W J	USM	CX-NDS8	
X	FLTR	R	0130	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0131	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0132	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0133	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0134	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0135	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8	
X	FLTR	R	0136	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8	

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	FLTR	R 0137	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FLTR	R 0138	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FLTR	R 0139	88-121-223-080	0E	RES,22K-1/8W J	USM	CX-NDS8
X	FLTR	R 0140	88-121-223-080	0E	RES,22K-1/8W J	USM	CX-NDS8
X	FLTR	R 0151	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	FLTR	R 0152	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FLTR	R 0153	88-118-683-080	0E	C-RES,S 68K-1/10W J	USM	CX-NDS8
X	FLTR	R 0154	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	FLTR	R 0157	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FLTR	R 0158	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
O	FLTR	R 0161	87-A00-441-050	0E	RES,270-1/2W J RP	USM	CX-NDS8
O	FLTR	R 0162	87-A00-441-050	0E	RES,270-1/2W J RP	USM	CX-NDS8
O	FLTR	R 0163	87-A00-441-050	0E	RES,270-1/2W J RP	USM	CX-NDS8
O	FLTR	R 0164	87-A00-441-050	0E	RES,270-1/2W J RP	USM	CX-NDS8
X	FLTR	R 0165	88-128-102-080	0E	C-RES, 1K-1/8W J	USM	CX-NDS8
X	FLTR	R 0170	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	FLTR	R 0171	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	FLTR	R 0172	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	FLTR	R 0173	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	FLTR	R 0174	88-130-100-080	0E	RES,10-1/4W J	USM	CX-NDS8
X	FLTR	R 0175	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	FLTR	R 0176	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	FLTR	R 0177	88-121-222-080	0E	RES,2.2K-1/8W J	USM	CX-NDS8
X	FLTR	R 0178	88-121-222-080	0E	RES,2.2K-1/8W J	USM	CX-NDS8
O	FRCB MECHA		8A-NF6-201-010	0E	GUIDE,FL	USM	CX-NDS8
O	FRCB MECHA		8A-NF6-203-010	0E	GUIDE,OPE	USM	CX-NDS8
O	FRCB MECHA		8A-NF6-204-010	0E	GUIDE,DECK	USM	CX-NDS8
O	FUNC/E.VR	C 0609	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0610	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0611	87-010-956-080	0E	C-CAP,S 0.068-25 K B GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0612	87-016-369-080	0E	C-CAP,S 0.033-25 K B GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0613	87-A11-567-080	0E	C-CAP,S 0.01-50 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0614	87-016-669-080	0E	C-CAP,S 0.1-25 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0616	87-010-184-080	0E	C-CAP,S 3300P-50 K B C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0617	87-012-369-080	0E	C-CAP,S 0.047-50 Z F	USM	CX-NDS8
O	FUNC/E.VR	C 0618	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0619	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0620	87-016-669-080	0E	C-CAP,S 0.1-25 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0621	87-A11-567-080	0E	C-CAP,S 0.01-50 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0623	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0624	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0626	87-A11-590-080	0E	C-CAP,S 0.047-16 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0627	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0628	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0629	87-A11-590-080	0E	C-CAP,S 0.047-16 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0630	87-010-383-080	0E	CAP,E 33-25 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0631	87-010-185-080	0E	C-CAP,S 3900P-50 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0632	87-010-185-080	0E	C-CAP,S 3900P-50 K B	USM	CX-NDS8
O	FUNC/E.VR	C 0633	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0634	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0635	87-A12-376-080	0E	CAP,M 0.1-100 J CP	USM	CX-NDS8
O	FUNC/E.VR	C 0636	87-A12-376-080	0E	CAP,M 0.1-100 J CP	USM	CX-NDS8
O	FUNC/E.VR	C 0637	87-A12-376-080	0E	CAP,M 0.1-100 J CP	USM	CX-NDS8
O	FUNC/E.VR	C 0638	87-A12-376-080	0E	CAP,M 0.1-100 J CP	USM	CX-NDS8
O	FUNC/E.VR	C 0639	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0641	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0642	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0643	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0644	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	FUNC/E.VR	C 0645	87-012-156-080	0E	C-CAP,S 220P-50 J CH GRM	USM	CX-NDS8
X	FUNC/E.VR	C 0661	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	C 0662	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	C 0663	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	C 0664	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
O	FUNC/E.VR	C 0671	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0672	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	FUNC/E.VR	C 0673	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0679	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0680	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	FUNC/E.VR	C 0682	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
! O	FUNC/E.VR	CN 0601	87-099-719-010	1B	CONN,30P H BLK TYK-B(X)	USM	CX-NDS8
! O	FUNC/E.VR	CN 0602	87-099-194-010	0E	CONN,6P V BLK 6216	USM	CX-NDS8
S	FUNC/E.VR	D 0602	87-A40-745-080	0E	ZENER,UZ4.7BSA	USM	CX-NDS8
S	FUNC/E.VR	D 0603	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
X	FUNC/E.VR	FB 0601	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
S	FUNC/E.VR	IC 0601	87-A21-452-130	1H	C-IC,BD3876AKS2	USM	CX-NDS8
O	FUNC/E.VR	J 0601	87-A60-885-010	1A	JACK,PIN 6P R/W MSC	USM	CX-NDS8
X	FUNC/E.VR	JR 0601	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0602	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0611	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0612	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	FUNC/E.VR	JR 0614	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	JR 0617	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0618	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0619	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	FUNC/E.VR	JR 0620	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0622	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0625	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0627	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	JR 0661	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
S	FUNC/E.VR	Q 0601	87-026-610-080	0E	TR,KTC3198GR	USM	CX-NDS8
S	FUNC/E.VR	Q 0605	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
S	FUNC/E.VR	Q 0606	87-A30-086-040	0E	C-TR,CSD1306E	USM	CX-NDS8
S	FUNC/E.VR	Q 0607	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	FUNC/E.VR	Q 0608	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	FUNC/E.VR	Q 0609	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
X	FUNC/E.VR	R 0601	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0602	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0603	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0604	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0605	88-121-333-080	0E	RES,33K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0606	88-121-333-080	0E	RES,33K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0607	88-121-472-080	0E	RES,4.7K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0608	88-121-472-080	0E	RES,4.7K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0609	88-121-392-080	0E	RES,3.9K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0610	88-121-392-080	0E	RES,3.9K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0611	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0612	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0613	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0614	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0615	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0616	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0617	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0618	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0619	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0620	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0621	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0622	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0623	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0624	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0625	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0626	88-130-330-080	0E	RES,33-1/4W J	USM	CX-NDS8
X	FUNC/E.VR	R 0627	88-128-390-080	0E	C-RES, 39-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0628	88-128-390-080	0E	C-RES, 39-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0629	88-128-330-080	0E	C-RES, 33-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0630	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0631	88-130-101-080	0E	RES,100-1/4W J	USM	CX-NDS8
X	FUNC/E.VR	R 0632	88-128-470-080	0E	C-RES, 47-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0633	88-128-470-080	0E	C-RES, 47-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0634	88-128-390-080	0E	C-RES, 39-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0635	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0636	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0637	88-130-101-080	0E	RES,100-1/4W J	USM	CX-NDS8
X	FUNC/E.VR	R 0638	88-128-390-080	0E	C-RES, 39-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0639	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0640	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0641	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0642	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0645	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0646	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	FUNC/E.VR	R 0647	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0648	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0651	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	FUNC/E.VR	R 0652	88-121-562-080	0E	RES,5.6K-1/8W J	USM	CX-NDS8
X	FUNC/E.VR	R 0657	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0659	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0660	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0661	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0662	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0663	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0664	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0665	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0666	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0671	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0672	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0673	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	FUNC/E.VR	R 0677	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0678	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0683	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	FUNC/E.VR	R 0684	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	KNOB		8A-NF6-021-010	-	KEY,POWER	USM	CX-NDS8
O	KNOB		8A-NF6-022-010	0E	KEY,ECHO	USM	CX-NDS8
X	KNOB		8A-NF6-025-010	0E	REFLECTOR,FUN	USM	CX-NDS8
O	KNOB		8A-NF6-026-010	1B	KEY,ASSY OPE	USM	CX-NDS8
X	KNOB		8A-NF6-027-010	0E	KEY,OPE	USM	CX-NDS8
X	KNOB		8A-NF6-028-010	0E	REFLECTOR,OPE	USM	CX-NDS8
O	KNOB		8A-NF6-030-010	0E	KNOB,RTYR JOG	USM	CX-NDS8
O	KNOB		8A-NF6-036-010	0E	KEY,CD EDIT	USM	CX-NDS8
O	KNOB		8A-NF6-037-110	1A	KEY,CD OPEN	USM	CX-NDS8
O	KNOB		8A-NF6-045-010	1A	KEY,ASSY POWER	USM	CX-NDS8
O	KNOB		8A-NF6-104-010	-	KEY,CD DIRECT 2	USM	CX-NDS8
O	KNOB		8A-NF6-105-010	-	KEY,T-BASS U 2	USM	CX-NDS8
X	KNOB		8A-NF6-202-010	-	GUIDE,FUN	USM	CX-NDS8
O	KNOB		8A-NFG-003-010	0E	KEY,DSP SURROUND	USM	CX-NDS8
O	KNOB		8A-NFG-004-010	0E	KEY,ASSY PRO ANF-16	USM	CX-NDS8
X	KNOB		8A-NFG-005-010	-	BTN,PRO ANF-16	USM	CX-NDS8
O	KNOB		8A-NFG-006-010	-	KEY,ASSY FUN ANF-16	USM	CX-NDS8
X	KNOB		8A-NFG-007-010	-	KEY,FUN ANF-16	USM	CX-NDS8
X	KNOB		8A-NFT-201-010	-	GUIDE,PRO	USM	CX-NDS8
X	LBL,POP		87-B40-034-010	1B	LBL,USA 1-800	USM	CX-NDS8
X	LBL,POP		8A-NF8-972-010	0E	LBL,POP ENG	USM	CX-NDS8
X	LBL,POP		8A-NFG-971-010	0E	LBL,POP UR	USM	CX-NDS8
X	LBL,POP		8A-NFT-970-010	1A	LBL,POP UL	USM	CX-NDS8
O	MACB MECHA	*	87-067-001-010	0E	S-SCREW,BVWVST2+3-12 W/O SLOT	USM	CX-NDS8
X	MACB MECHA	*	8A-NF6-227-010	1B	HT-SINK,VM 2	USM	CX-NDS8
X	MECHANICAL		8A-NF6-211-210	1F	CHAS,MAIN	USM	CX-NDS8
O	MIC	C 0601	87-010-186-080	0E	C-CAP,S 4700P-50 K B C2012	USM	CX-NDS8
O	MIC	C 0602	87-010-405-040	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	MIC	C 0603	87-010-320-080	0E	C-CAP,S 68P-50 J CH GRM	USM	CX-NDS8
O	MIC	C 0604	87-010-546-040	0E	CAP,E 0.33-50 M 11L SME	USM	CX-NDS8
O	MIC	C 0605	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8
O	MIC	C 0606	87-010-112-040	0E	CAP,E 100-16 M 11L SME	USM	CX-NDS8
O	MIC	C 0607	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MIC	C 0608	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	MIC	C 0621	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	MIC	CN 0601	87-099-211-010	0E	CONN,4P V BLK 6216	USM	CX-NDS8
O	MIC	FB 0601	87-008-372-080	0E	FLTR,EMI BL01 RN1	USM	CX-NDS8
O	MIC	J 0601	87-A61-242-010	1A	JACK,6.3 BLK MONO W/SW V KM	USM	CX-NDS8
O	MIC	J 0602	87-A61-242-010	1A	JACK,6.3 BLK MONO W/SW V KM	USM	CX-NDS8
S	MIC	Q 0601	87-A30-087-080	0E	C-FET,2SK2158	USM	CX-NDS8
S	MIC	Q 0602	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	MIC	Q 0603	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	MIC	Q 0604	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
X	MIC	R 0601	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MIC	R 0602	88-118-334-080	0E	C-RES,S 330K-1/10W J	USM	CX-NDS8
X	MIC	R 0603	88-118-154-080	0E	C-RES,S 150K-1/10W J	USM	CX-NDS8
X	MIC	R 0604	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	MIC	R 0605	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	MIC	R 0606	88-118-334-080	0E	C-RES,S 330K-1/10W J	USM	CX-NDS8
X	MIC	R 0607	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	MIC	R 0608	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MIC	R 0609	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	MIC	R 0610	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	MIC	R 0611	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	MIC	R 0612	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MIC	R 0613	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	*	8A-NFG-615-010	1D	PWB,COMB FRONT ANF-G	USM	CX-NDS8
X	MICON	*	8A-NFG-616-010		- PWB,FRONT ANF-G	USM	CX-NDS8
X	MICON	*	8A-NFG-617-010		- PWB,CD KEY ANF-G	USM	CX-NDS8
X	MICON	*	8A-NFG-618-010		- PWB,MIC ANF-G	USM	CX-NDS8
O	MICON	C 0101	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	MICON	C 0102	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0103	87-010-312-080	0E	C-CAP,S 15P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0104	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0105	87-010-415-040	0E	CAP,E 10-50 M 5L SRE	USM	CX-NDS8
O	MICON	C 0106	87-010-493-040	0E	CAP,E 0.47-50 M 5L SRE	USM	CX-NDS8
O	MICON	C 0107	87-A10-189-040	0E	CAP,E 220-10 M 5L	USM	CX-NDS8
O	MICON	C 0108	87-A10-189-040	0E	CAP,E 220-10 M 5L	USM	CX-NDS8
O	MICON	C 0109	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0110	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	MICON	C 0112	87-012-368-080	0E	C-CAP,S 0.1-50 Z F	USM	CX-NDS8
O	MICON	C 0113	87-010-596-080	0E	C-CAP,S 0.047-16 K R C2012	USM	CX-NDS8
O	MICON	C 0114	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0115	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0116	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0118	87-012-145-080	0E	C-CAP,S 270P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0180	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	MICON	C 0181	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	MICON	C 0202	87-012-156-080	0E	C-CAP,S 220P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0203	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0204	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0205	87-012-156-080	0E	C-CAP,S 220P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0214	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0215	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0216	87-010-177-080	0E	C-CAP,S 820P-50 J SL C2012	USM	CX-NDS8
O	MICON	C 0221	87-010-421-040	0E	CAP,E 4.7-50 M 5L SRE	USM	CX-NDS8
O	MICON	C 0222	87-010-421-040	0E	CAP,E 4.7-50 M 5L SRE	USM	CX-NDS8
O	MICON	C 0223	87-010-408-040	0E	CAP,E 47-50 M 11L SME	USM	CX-NDS8
O	MICON	C 0224	87-012-369-080	0E	C-CAP,S 0.047-50 Z F	USM	CX-NDS8
O	MICON	C 0312	87-010-498-040	0E	CAP,E 10-16 M 5L SRE	USM	CX-NDS8
O	MICON	C 0314	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0315	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0316	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0321	87-012-393-080	0E	C-CAP,S 0.22-16 K W5R CM/CB	USM	CX-NDS8
O	MICON	C 0382	87-010-320-080	0E	C-CAP,S 68P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0383	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0384	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0385	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0386	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0387	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0392	87-010-320-080	0E	C-CAP,S 68P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0401	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0402	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0403	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0404	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0405	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0406	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0407	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0408	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	MICON	C 0461	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0462	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0463	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0464	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	MICON	C 0465	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
X	MICON	C 0651	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	MICON	C 0652	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	MICON	C 0653	87-010-213-080	0E	C-CAP,S 0.015-25 K B GRM	USM	CX-NDS8
O	MICON	C 0701	87-010-406-040	0E	CAP,E 22-50 M 11L SME	USM	CX-NDS8
!	O MICON	CN 0101	87-099-720-010	1B	CONN,30P BLK TYK-B(P)	USM	CX-NDS8
!	O MICON	CN 0103	87-099-013-010	0E	CONN,11P V BLK 6216	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
! O	MICON	CN 0104	87-099-017-010	0E	CONN,15P V BLK 6216	USM	CX-NDS8
! O	MICON	CN 0301	87-099-195-010	0E	CONN,7P V BLK 6216	USM	CX-NDS8
! O	MICON	CN 0302	87-099-195-010	0E	CONN,7P V BLK 6216	USM	CX-NDS8
! O	MICON	CN 0602	87-099-209-010	0E	CONN,4P H BLK 6216	USM	CX-NDS8
O	MICON	CN 0901	87-A60-161-010	0E	CONN,13P H FE	USM	CX-NDS8
S	MICON	D 0101	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0102	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0105	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0106	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0107	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0108	87-A40-752-080	0E	ZENER,UZ6.2BSC	USM	CX-NDS8
S	MICON	D 0301	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0302	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0303	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0304	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0305	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0306	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0307	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0308	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0309	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0310	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0311	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0312	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0313	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0314	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0315	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0316	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0318	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0322	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0330	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0381	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0382	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0383	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0384	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0385	87-A40-802-080	0E	ZENER,UZ5.1BSC	USM	CX-NDS8
S	MICON	D 0401	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	MICON	D 0701	87-A40-269-080	0E	C-DIODE,MC2836	USM	CX-NDS8
X	MICON	D 0901	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
S	MICON	D 0902	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
O	MICON	FL 0201	8A-NFG-601-010	2B	FL,BJ789GNK 13G-35S ANF-16	USM	CX-NDS8
S	MICON	IC 0101	8A-NFG-605-030	-	C-IC,LC876572V-5S31	USM	CX-NDS8
S	MICON	IC 0251	87-A20-914-010	1B	IC,SPS-442-1-F	USM	CX-NDS8
S	MICON	IC 0380	87-A21-577-040	1C	C-IC,M61506FP	USM	CX-NDS8
S	MICON	IC 0401	87-A21-021-040	1B	C-IC,BU2099FV	USM	CX-NDS8
S	MICON	IC 0402	87-070-289-040	1B	C-IC,BU2092F	USM	CX-NDS8
X	MICON	JR 0101	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MICON	JR 0103	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MICON	JR 0104	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MICON	JR 0105	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MICON	JR 0108	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	MICON	L 0101	87-A50-333-010	0E	COIL,OSC 9.43MHZ	USM	CX-NDS8
X	MICON	L 0201	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	MICON	L 0202	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
O	MICON	LED0401	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0402	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0403	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0404	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0405	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0406	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0407	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0408	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0409	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0410	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0416	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0417	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0418	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0419	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0420	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0421	87-A40-809-080	0E	LED,LTL-307KK PGRN	USM	CX-NDS8
O	MICON	LED0431	87-A40-930-040	1D	LED,E1L55-7B0A6 BLUE	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	MICON	LED0432	87-A40-930-040	1D	LED,E1L55-7B0A6 BLUE	USM	CX-NDS8
O	MICON	LED0433	87-A40-678-010	1D	LED,SELU1E10CXM BLUE-DEF	USM	CX-NDS8
O	MICON	LED0440	87-A40-929-010	-	LED,EL-2363-2UBC BLUE	USM	CX-NDS8
O	MICON	LED0441	87-A40-929-010	-	LED,EL-2363-2UBC BLUE	USM	CX-NDS8
O	MICON	LED0451	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0452	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0453	87-017-756-040	0E	LED,SLR-342DCT31 ORN	USM	CX-NDS8
O	MICON	LED0454	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0455	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0456	87-A40-496-040	0E	LED,SLR-342PCT31 GRN	USM	CX-NDS8
O	MICON	LED0499	87-A40-317-080	0E	LED,SLR-342VCT31 RED	USM	CX-NDS8
S	MICON	Q 0101	87-A30-087-080	0E	C-FET,2SK2158	USM	CX-NDS8
S	MICON	Q 0102	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	MICON	Q 0103	87-A30-468-080	0E	C-TR,KRC102S-RTK	USM	CX-NDS8
S	MICON	Q 0104	87-A30-074-080	0E	C-TR,RT1P 141C	USM	CX-NDS8
S	MICON	Q 0105	87-A30-074-080	0E	C-TR,RT1P 141C	USM	CX-NDS8
S	MICON	Q 0107	87-026-610-080	0E	TR,KTC3198GR	USM	CX-NDS8
S	MICON	Q 0108	87-A30-074-080	0E	C-TR,RT1P 141C	USM	CX-NDS8
S	MICON	Q 0401	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	MICON	Q 0701	87-A30-329-080	0E	TR,CD1585BC	USM	CX-NDS8
S	MICON	Q 0704	87-A30-495-080	0E	TR,2SA1981Y	USM	CX-NDS8
S	MICON	Q 0705	87-A30-495-080	0E	TR,2SA1981Y	USM	CX-NDS8
X	MICON	R 0101	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0104	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0105	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0106	88-118-391-080	0E	C-RES,S 390-1/10W J	USM	CX-NDS8
X	MICON	R 0107	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0108	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	MICON	R 0109	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0110	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0111	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0112	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0113	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0114	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0115	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0116	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0117	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	MICON	R 0118	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0120	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0121	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0122	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0123	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	MICON	R 0124	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	MICON	R 0125	88-121-101-080	0E	RES,100-1/8W J	USM	CX-NDS8
X	MICON	R 0126	88-121-224-080	0E	RES,220K-1/8W J	USM	CX-NDS8
X	MICON	R 0127	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0130	88-128-223-080	0E	C-RES, 22K-1/8W J	USM	CX-NDS8
X	MICON	R 0132	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	MICON	R 0133	88-118-683-080	0E	C-RES,S 68K-1/10W J	USM	CX-NDS8
X	MICON	R 0134	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0135	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	MICON	R 0136	88-121-222-080	0E	RES,2.2K-1/8W J	USM	CX-NDS8
X	MICON	R 0137	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	MICON	R 0138	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	MICON	R 0140	88-128-109-080	0E	C-RES, 1-1/8W J	USM	CX-NDS8
X	MICON	R 0141	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	MICON	R 0156	88-121-683-080	0E	RES,68K-1/8W J	USM	CX-NDS8
X	MICON	R 0159	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	MICON	R 0160	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	MICON	R 0162	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0163	88-128-181-080	0E	C-RES, 180-1/8W J	USM	CX-NDS8
X	MICON	R 0181	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	MICON	R 0182	88-118-683-080	0E	C-RES,S 68K-1/10W J	USM	CX-NDS8
X	MICON	R 0183	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0184	88-118-184-080	0E	C-RES,S 180K-1/10W J	USM	CX-NDS8
X	MICON	R 0185	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0186	88-118-683-080	0E	C-RES,S 68K-1/10W J	USM	CX-NDS8
X	MICON	R 0187	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0188	88-118-184-080	0E	C-RES,S 180K-1/10W J	USM	CX-NDS8
X	MICON	R 0189	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	MICON	R 0190	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	MICON	R 0191	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	MICON	R 0201	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0202	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0203	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0204	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0205	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0206	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0207	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0208	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0209	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0210	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0211	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0212	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0213	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	MICON	R 0214	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0215	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0216	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0217	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0218	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0219	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0220	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0221	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0222	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0223	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0224	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0225	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0226	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0227	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0228	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0229	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0230	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0231	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0232	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0233	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0234	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0235	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	MICON	R 0236	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0237	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0238	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0239	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0240	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0241	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0242	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0243	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0244	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0245	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0246	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0247	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0248	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0249	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	MICON	R 0251	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	MICON	R 0255	88-128-472-080	0E	C-RES, 4.7K-1/8W J	USM	CX-NDS8
X	MICON	R 0256	88-128-102-080	0E	C-RES, 1K-1/8W J	USM	CX-NDS8
X	MICON	R 0257	88-128-472-080	0E	C-RES, 4.7K-1/8W J	USM	CX-NDS8
X	MICON	R 0258	88-128-102-080	0E	C-RES, 1K-1/8W J	USM	CX-NDS8
X	MICON	R 0259	88-118-100-080	0E	C-RES,S 10-1/10W J	USM	CX-NDS8
X	MICON	R 0261	88-118-391-080	0E	C-RES,S 390-1/10W J	USM	CX-NDS8
X	MICON	R 0262	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0263	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	MICON	R 0311	88-121-103-080	0E	RES,10K-1/8W J	USM	CX-NDS8
X	MICON	R 0312	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0313	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	MICON	R 0314	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0315	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0316	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0317	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0318	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0319	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0320	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	MICON	R 0321	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0322	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0323	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0331	88-128-103-080	0E	C-RES, 10K-1/8W J	USM	CX-NDS8
X	MICON	R 0332	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0333	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	MICON	R 0334	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0335	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0336	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0337	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0338	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0339	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0340	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	MICON	R 0341	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0342	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0343	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0344	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	MICON	R 0351	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0352	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0353	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	MICON	R 0354	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0355	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0356	88-118-122-080	0E	C-RES,S 1.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0357	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0358	88-118-182-080	0E	C-RES,S 1.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0359	88-118-272-080	0E	C-RES,S 2.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0360	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	MICON	R 0361	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0362	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	MICON	R 0363	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0364	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	MICON	R 0365	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0367	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0368	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0369	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0370	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0371	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0372	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0373	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0374	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	MICON	R 0380	88-118-124-080	0E	C-RES,S 120K-1/10W J	USM	CX-NDS8
X	MICON	R 0381	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0382	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0383	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	MICON	R 0384	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0385	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	MICON	R 0386	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	MICON	R 0387	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	MICON	R 0388	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	MICON	R 0389	88-118-273-080	0E	C-RES,S 27K-1/10W J	USM	CX-NDS8
X	MICON	R 0390	88-128-391-080	0E	C-RES, 390-1/8W J	USM	CX-NDS8
X	MICON	R 0391	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0392	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0393	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0394	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0395	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0397	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	MICON	R 0401	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0402	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0403	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0404	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0407	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0408	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0409	88-128-101-080	0E	C-RES, 100-1/8W J	USM	CX-NDS8
X	MICON	R 0411	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0412	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0413	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0414	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0415	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0416	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	MICON	R 0417	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0418	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0419	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0420	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0431	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0432	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0433	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0434	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0435	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0436	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0438	88-128-561-080	0E	C-RES, 560-1/8W J	USM	CX-NDS8
X	MICON	R 0439	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0440	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0441	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0450	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0452	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0455	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0456	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0457	88-128-681-080	0E	C-RES, 680-1/8W J	USM	CX-NDS8
X	MICON	R 0458	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0459	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0461	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0462	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0463	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0464	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0465	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0499	88-118-392-080	0E	C-RES,S 3.9K-1/10W J	USM	CX-NDS8
X	MICON	R 0653	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0654	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	MICON	R 0702	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0703	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0704	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0705	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	MICON	R 0706	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	MICON	R 0707	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0711	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0712	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0713	88-128-473-080	0E	C-RES, 47K-1/8W J	USM	CX-NDS8
X	MICON	R 0714	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	MICON	R 0715	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0716	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0717	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	MICON	R 0718	88-128-473-080	0E	C-RES, 47K-1/8W J	USM	CX-NDS8
X	MICON	R 0901	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0902	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0903	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0904	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0906	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0907	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0908	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0909	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0910	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0911	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0912	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0913	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	MICON	R 0914	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8
X	MICON	R 0915	88-118-823-080	0E	C-RES,S 82K-1/10W J	USM	CX-NDS8
O	MICON	S 0101	87-A91-591-010	1B	SW,RTRY RE0121PVB25FINA24	USM	CX-NDS8
O	MICON	S 0102	87-A91-664-010	1A	SW,RTRY RE0121PVB30F	USM	CX-NDS8
O	MICON	S 0301	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0302	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0303	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0304	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0305	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0306	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0310	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0311	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0312	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0313	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8
O	MICON	S 0321	87-A91-024-180	0E	SW,TACT KSHG611BT	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	MICON	S	0322	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0323	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0324	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0325	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0326	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0327	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0328	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0333	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0334	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0341	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0342	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0343	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0344	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0345	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0346	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0347	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0349	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0350	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0351	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0352	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0353	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0354	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	MICON	S	0355	87-A91-024-180	0E	SW, TACT KSHG611BT	USM CX-NDS8
O	OTHERS		82-CD5-219-010	0E	W-F, 3.2-6-0.25	USM CX-NDS8	
!	X OTHERS		82-JT1-206-010	0E	CLOTH, 15-50-0.5	USM CX-NDS8	
O	OTHERS		82-NF5-218-010	0E	SPR-T, EJECT 1(SIN)	USM CX-NDS8	
O	OTHERS		82-NF5-219-010	0E	SPR-T, EJECT 2(SIN)	USM CX-NDS8	
!	O OTHERS		82-NF5-229-010	0E	PLATE, LOCK(*)	USM CX-NDS8	
X	OTHERS		83-CD7-594-010	0E	SH, 4-4-0.188	USM CX-NDS8	
O	OTHERS		86-NF9-224-010	0E	SPR-C, LOCK	USM CX-NDS8	
!	X OTHERS		86-NFZ-205-010	0E	CUSH, 12.5-15.5-2 (NP)	USM CX-NDS8	
X	OTHERS		87-063-173-010	0E	CLOTH, N9295B BLK 30-10-0.35	USM CX-NDS8	
O	OTHERS		87-064-185-010	0E	HLDR, WIRE PVC 0.5	USM CX-NDS8	
O	OTHERS		87-084-077-010	0E	RIVET, NYL3.5-4.5	USM CX-NDS8	
!	O OTHERS		87-NF4-216-010	0E	HLDR, LOCK 1	USM CX-NDS8	
!	O OTHERS		87-NF4-217-110	0E	HLDR, LOCK 2	USM CX-NDS8	
!	O OTHERS		87-NF4-221-010	0E	HLDR, CABLE	USM CX-NDS8	
X	OTHERS		8A-NF6-209-010	1E	PLATE, PT 96-75	USM CX-NDS8	
O	OTHERS		8A-NF6-210-110	0E	HLDR, IC6	USM CX-NDS8	
X	OTHERS		8A-NF6-220-010	0E	SH, 10-1.9-0.3 W/ADH	USM CX-NDS8	
!	O OTHERS		8A-NF6-228-010	0E	HLDR, PWB PT 96-75	USM CX-NDS8	
X	OTHERS		8A-NF6-599-010	0E	SH, 4-10-0.34 W/ADH BLK	USM CX-NDS8	
O	OTHERS		8A-NFG-201-010	0E	HLDR, PWB 1	USM CX-NDS8	
O	OTHERS		8A-NFG-202-010	0E	HLDR, PWB 2	USM CX-NDS8	
X	OTHERS		8Z-NF5-204-110	1A	PLATE, SHLD MECHA	USM CX-NDS8	
!	O OTHERS		8Z-NF6-210-010	0E	DMPR, 150 N	USM CX-NDS8	
O	OTHERS	*	8A-NF6-205-010	0E	GUIDE, CD	USM CX-NDS8	
O	OTHERS	*	8A-NF6-213-010	1A	HLDR, HT-SINK L	USM CX-NDS8	
O	OTHERS	*	8A-NF6-214-010	0E	HLDR, HT-SINK R	USM CX-NDS8	
X	OTHERS	*	8A-NF6-215-010	0E	PLATE, EARTH MIC	USM CX-NDS8	
O	OTHERS	*	8A-NF6-219-010	1A	HLDR, FAN	USM CX-NDS8	
X	OTHERS	*	8A-NF6-223-010	0E	HT-SINK, FIN 105	USM CX-NDS8	
O	OTHERS	*	8A-NF7-209-010	0E	HLDR, PWB-M BTM	USM CX-NDS8	
!	O OTHERS	*	8A-NF8-206-010	0E	HLDR, PWB M	USM CX-NDS8	
X	OTHERS	*	8A-NFT-202-010	0E	HT-SINK, T7.5FAN	USM CX-NDS8	
X	OTHERS	*	8A-NFT-203-010	2M	HT-SINK, ASSY	USM CX-NDS8	
X	P-SUPPLY/PWB/FAN	*	8A-NFG-634-010	0E	PWB, DOLBY DIGITAL	USM CX-NDS8	
X	P-SUPPLY/PWB/FAN	*	8A-NFG-631-010	1F	PWB, COMB MAIN ANF-G	USM CX-NDS8	
X	P-SUPPLY/PWB/FAN	*	8A-NFG-632-010	0E	PWB, MAIN	USM CX-NDS8	
X	P-SUPPLY/PWB/FAN	*	8A-NFG-636-010	0E	PWB, VM	USM CX-NDS8	
O	P-SUPPLY/PWB/FAN	C	0003	87-012-368-080	0E	C-CAP, S 0.1-50 Z F	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0004	87-012-368-080	0E	C-CAP, S 0.1-50 Z F	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0021	87-016-658-000	1C	CAP, E 4700-35 M SMG	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0022	87-016-658-000	1C	CAP, E 4700-35 M SMG	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0025	87-010-247-080	0E	CAP, E 100-50 M SME	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0026	87-010-247-080	0E	CAP, E 100-50 M SME	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0027	87-010-247-080	0E	CAP, E 100-50 M SME	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0028	87-010-247-080	0E	CAP, E 100-50 M SME	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0031	87-010-263-080	0E	CAP, E 100-10 M 11L SME	USM CX-NDS8
O	P-SUPPLY/PWB/FAN	C	0032	87-010-197-080	0E	C-CAP, S 0.01-25 K-B C2012	USM CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	P-SUPPLY/PWB/FAN	C 0033	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0034	87-010-247-080	0E	CAP,E 100-50 M SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0035	87-010-384-080	0E	CAP,E 100-25 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0036	87-010-235-080	0E	CAP,E 470-16 M SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0038	87-010-430-080	0E	CAP,E 100-63	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0040	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0060	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0071	87-010-235-080	0E	CAP,E 470-16 M SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0072	87-010-258-080	0E	CAP,E 22-35 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0080	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0081	87-010-379-080	0E	CAP,E 22-16 M 11L SME	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	C 0082	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
!	O P-SUPPLY/PWB/FAN	CN 0001	87-A60-996-010	0E	CONN,13P V BLK TAC-L13X-A3	USM	CX-NDS8
!	O P-SUPPLY/PWB/FAN	CN 0091	87-A60-109-010	0E	CONN,2P V S2M-2W	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	CNA0001	8A-NF6-646-010	1A	CONN ASSY,9P TID-A(460)	USM	CX-NDS8
O	P-SUPPLY/PWB/FAN	CNA0002	8A-NF6-640-010	1A	CONN ASSY,3P (VM) ANF-6H	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0001	87-A40-673-090	1B	DIODE,D10XB20	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0025	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0026	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0027	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0028	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0029	87-A40-784-080	0E	ZENER,UZ39BSB	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0030	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0031	87-A40-764-080	0E	ZENER,UZ10BSC	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0033	87-A40-553-080	0E	DIODE,1N4003 LES	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0034	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0035	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0060	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0061	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0062	87-A40-313-080	0E	C-DIODE,MC2840	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0063	87-A40-270-080	0E	C-DIODE,MC2838	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0064	87-A40-269-080	0E	C-DIODE,MC2836	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0065	87-A40-768-080	0E	ZENER,UZ16BSA	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0071	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0084	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	D 0085	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	JR 0002	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0001	87-026-609-080	0E	TR,KTA1266GR	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0002	87-026-609-080	0E	TR,KTA1266GR	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0005	87-026-610-080	0E	TR,KTC3198GR	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0006	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0007	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0008	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0009	89-213-702-010	1A	TR,2SB1370E	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0010	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0013	89-213-702-010	1A	TR,2SB1370E	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0014	89-213-702-010	1A	TR,2SB1370E	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0060	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0061	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0062	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0063	87-A30-075-080	0E	C-TR,2SA1235F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0064	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0071	89-110-372-080	0E	C-TR,2SA1037K(R)	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0072	89-213-702-010	1A	TR,2SB1370E	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0081	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	P-SUPPLY/PWB/FAN	Q 0084	87-026-609-080	0E	TR,KTA1266GR	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0001	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0005	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0011	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0012	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0013	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0014	88-118-100-080	0E	C-RES,S 10-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0015	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0016	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0019	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0020	88-118-680-080	0E	C-RES,S 68-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0021	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0022	88-118-221-080	0E	C-RES,S 220-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0023	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0024	88-118-109-080	0E	C-RES,S 1-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	P-SUPPLY/PWB/FAN	R 0026	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0027	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0028	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0029	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0030	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0031	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0032	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0033	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0034	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0035	88-128-129-080	0E	C-RES, 1.2-1/8W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0036	88-128-129-080	0E	C-RES, 1.2-1/8W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0037	88-118-394-080	0E	C-RES,S 390K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0038	88-128-103-080	0E	C-RES, 10K-1/8W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0039	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0041	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0042	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0052	88-128-822-080	0E	C-RES, 8.2K-1/8W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0053	88-128-822-080	0E	C-RES, 8.2K-1/8W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0056	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0059	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0061	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0062	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0063	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0064	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0065	88-118-123-080	0E	C-RES,S 12K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0067	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0068	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0070	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0071	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0072	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0073	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0074	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0075	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0076	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0077	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0084	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0085	88-118-472-080	0E	C-RES,S 4.7K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0086	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0087	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0088	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0089	88-118-221-080	0E	C-RES,S 220-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0090	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0091	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	P-SUPPLY/PWB/FAN	R 0092	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
!	O P-SUPPLY/PWB/FAN	WH 0001	87-A90-510-010	0E	HLDLR,WIRE 2.5-9P	USM	CX-NDS8
X	PACKING		86-NFA-860-010	0E	PAD,BOX	USM	CX-NDS8
X	PACKING		87-B40-057-010	0E	BAG,PP 0.03-150-200	USM	CX-NDS8
X	PACKING		87-B40-098-010	0E	BAG,PV 0.025-650-750 PL	USM	CX-NDS8
X	PACKING		8A-NF6-853-210	1B	CUSHION,FRONT M	USM	CX-NDS8
X	PACKING		8A-NF6-854-010	1B	CUSHION,REAR M	USM	CX-NDS8
X	PACKING		8A-NFG-851-010	1E	CTN,PRINTED USM	USM	CX-NDS8
X	PACKING		93-704-337-010	1A	SH,FOAMED-MAT 0.31-800-500	USM	CX-NDS8
O	PLATE		81-532-080-010	1A	LBL,CASS-COMPT	USM	CX-NDS8
X	PLATE		84-711-909-010	1A	LBL DATE CODE	USM	CX-NDS8
X	PLATE		87-B40-016-010	0E	BAG,PP (BAR-CODE)	USM	CX-NDS8
X	PLATE		87-B40-287-010	0E	LBL,BAR-CODE EU 35X8	USM	CX-NDS8
O	PLATE		8A-NF6-038-010	0E	REFLECTOR,FL	USM	CX-NDS8
O	PLATE		8A-NF6-039-010	0E	REFLECTOR,DECK	USM	CX-NDS8
O	PLATE		8A-NF6-040-010	0E	REFLECTOR,VOL	USM	CX-NDS8
O	PLATE		8A-NF6-042-010	0E	REFLECTOR,ECO	USM	CX-NDS8
X	PLATE		8A-NF6-043-010	0E	SH,CD	USM	CX-NDS8
O	PLATE		8A-NF6-044-010	0E	REFLECTOR,CD	USM	CX-NDS8
X	PRINTED DU		87-B40-086-010	0E	BAG,PV 0.04-230-400 PL	USM	CX-NDS8
X	PRINTED DU		87-B50-053-010	0E	WARR-CARD,USA CUST/AV,VISUAL	USM	CX-NDS8
O	PRINTED DU		8A-NFG-903-010	-	IB,U(ESF)M	USM	CX-NDS8
X	PT	*	8A-NF6-641-110	1C	PWB,PT 96-60	USM	CX-NDS8
O	PT	C 0001	87-010-387-080	1A	CAP,E 470-25 M SME	USM	CX-NDS8
O	PT	C 0004	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8
O	PT	C 0005	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8
O	PT	C 0006	87-010-917-000	1D	CAP,E 3300-50 M SMG	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME		
O	PT	C	0007	87-010-917-000	1D	CAP,E 3300-50 M SMG	USM	CX-NDS8	
O	PT	C	0008	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8	
O	PT	C	0009	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8	
O	PT	C	0010	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8	
O	PT	C	0011	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	USM	CX-NDS8	
O	PT	C	0012	87-016-520-000	1D	CAP,E 3300-65 M SMG	USM	CX-NDS8	
O	PT	C	0013	87-016-520-000	1D	CAP,E 3300-65 M SMG	USM	CX-NDS8	
X	PT	C	0014	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	C	0015	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
O	PT	C	0016	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8	
!	O	PT	CN	0001	87-A61-110-010	0E	CONN,9P V TID-A	USM	CX-NDS8
!	O	PT	CN	0002	87-A61-108-010	0E	CONN,5P V TID-A	USM	CX-NDS8
S	PT	D	0001	87-A40-673-090	1B	DIODE,D10XB20	USM	CX-NDS8	
S	PT	D	0002	87-A40-673-090	1B	DIODE,D10XB20	USM	CX-NDS8	
S	PT	D	0004	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0005	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0006	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0007	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0008	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0009	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0010	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0011	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0012	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0013	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0014	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0015	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0016	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0017	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0018	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0019	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0020	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
S	PT	D	0021	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8	
!	S	PT	F	0001	87-A91-806-010	1A	FUSE,10A 125V 237-0101P	USM	CX-NDS8
X	PT	PR	0001	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0002	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0003	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0004	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0005	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0006	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
X	PT	PR	0009	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8	
!	O	PT	PT	0002	8A-NF8-661-010	1C	PT,SUB ANF-8 (U)	USM	CX-NDS8
S	PT	Q	0001	87-026-245-080	0E	TR,DTC114ES	USM	CX-NDS8	
S	PT	Q	0002	87-026-610-080	0E	TR,KTC3198GR	USM	CX-NDS8	
X	PT	R	0001	88-121-183-080	0E	RES,18K-1/8W J	USM	CX-NDS8	
X	PT	R	0002	88-121-183-080	0E	RES,18K-1/8W J	USM	CX-NDS8	
X	PT	R	0003	88-121-822-080	0E	RES,8.2K-1/8W J	USM	CX-NDS8	
X	PT	R	0004	88-130-183-080	0E	RES,18K-1/4W J	USM	CX-NDS8	
X	PT	R	0005	88-130-183-080	0E	RES,18K-1/4W J	USM	CX-NDS8	
X	PT	R	0006	88-121-153-080	0E	RES,15K-1/8W J	USM	CX-NDS8	
X	PT	R	0008	88-121-333-080	0E	RES,33K-1/8W J	USM	CX-NDS8	
X	PT	R	0010	88-121-473-080	0E	RES,47K-1/8W J	USM	CX-NDS8	
X	PT	R	0011	88-121-104-080	0E	RES,100K-1/8W J	USM	CX-NDS8	
X	PT	R	0012	88-121-104-080	0E	RES,100K-1/8W J	USM	CX-NDS8	
X	PT	R	0013	88-130-101-080	0E	RES,100-1/4W J	USM	CX-NDS8	
X	PT	R	0014	88-121-333-080	0E	RES,33K-1/8W J	USM	CX-NDS8	
X	PT	R	0017	88-121-333-080	0E	RES,33K-1/8W J	USM	CX-NDS8	
X	PT	R	0018	88-121-473-080	0E	RES,47K-1/8W J	USM	CX-NDS8	
X	PT	R	0099	88-140-225-080	0E	RES,2.2M-1/2W J	USM	CX-NDS8	
!	O	PT	RY	0002	87-A90-976-010	1B	RELAY,AC12V SDT-S-112LMR	USM	CX-NDS8
O	PT	T	0001	87-A60-317-010	0E	TERMINAL, 1P MSC	USM	CX-NDS8	
O	PT	T	0002	87-A60-317-010	0E	TERMINAL, 1P MSC	USM	CX-NDS8	
O	SCREW			87-067-579-010	0E	BVT2+3-8 W/O SL0T	USM	CX-NDS8	
O	SCREW			87-067-581-010	0E	BVT2+3-15 W/O SL0T	USM	CX-NDS8	
O	SCREW			87-067-688-010	0E	BVT+3-6	USM	CX-NDS8	
O	SCREW			87-067-703-010	0E	BVT2+3-10 W/O SL0T	USM	CX-NDS8	
O	SCREW			87-067-758-010	0E	BVT2+3-12 W/O SL0T	USM	CX-NDS8	
O	SCREW			87-067-975-010	0E	S-SCREW,IT+4-8 SWCH12A	USM	CX-NDS8	
O	SCREW			87-591-094-410	0E	QIT+3-6	USM	CX-NDS8	
O	SCREW			87-591-095-410	0E	QIT+3-8	USM	CX-NDS8	
O	SCREW			87-721-097-410	0E	QT2+3-12 W/O SLOT	USM	CX-NDS8	

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	SCREW		87-723-096-410	0E	QT2+3-10 W/O SLOT BLK	USM	CX-NDS8
O	SCREW		87-B10-091-010	0E	UTT2+3-10 W/O SLOT BLK	USM	CX-NDS8
O	SCREW		87-NF4-224-010	0E	S-SCREW,IT3B+3-8 CU	USM	CX-NDS8
X	TAPE		80-MQ1-209-010	0E	CLOTH,20-7	USM	CX-NDS8
!	X TAPE		87-069-033-010	0E	CABLE,TIE	USM	CX-NDS8
O	TAPE		87-NF6-615-010	0E	CONN ASSY,3P PB	USM	CX-NDS8
O	TAPE		87-NF6-616-010	1B	CONN ASSY,8P RPB	USM	CX-NDS8
!	X TAPE		M8-2ZM-384-030		- 2ZM-3MK2 PR7NM	USM	CX-NDS8
O	TAPE DECK	C 0301	87-010-318-080	0E	C-CAP,S 47P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0302	87-010-318-080	0E	C-CAP,S 47P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0303	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0304	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0305	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0306	87-012-157-080	0E	C-CAP,S 330P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0307	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0309	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0310	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0311	87-010-198-080	0E	C-CAP,S 0.022-25 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0312	87-010-198-080	0E	C-CAP,S 0.022-25 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0313	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0314	87-010-181-080	0E	C-CAP,S 1800P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0315	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0316	87-010-179-080	0E	C-CAP,S 1200P-50 K B GRM	USM	CX-NDS8
X	TAPE DECK	C 0317	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TAPE DECK	C 0318	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TAPE DECK	C 0321	87-012-142-080	0E	C-CAP,S 0.33-16 Z F GRM	USM	CX-NDS8
O	TAPE DECK	C 0322	87-012-142-080	0E	C-CAP,S 0.33-16 Z F GRM	USM	CX-NDS8
O	TAPE DECK	C 0324	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0325	87-010-370-080	0E	CAP,E 330-6.3 M SME	USM	CX-NDS8
O	TAPE DECK	C 0327	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0328	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0332	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0335	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0336	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0337	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0339	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0340	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0351	87-012-140-080	0E	C-CAP,S 470P-50 J CH	USM	CX-NDS8
O	TAPE DECK	C 0352	87-012-140-080	0E	C-CAP,S 470P-50 J CH	USM	CX-NDS8
O	TAPE DECK	C 0354	87-010-175-080	0E	C-CAP,S 560P-50 J SL	USM	CX-NDS8
O	TAPE DECK	C 0355	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0356	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0357	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0358	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0359	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0360	87-010-183-080	0E	C-CAP,S 2700P-50 K B GRM	USM	CX-NDS8
O	TAPE DECK	C 0363	87-A12-361-080	0E	CAP,M 5600P-100 J CP	USM	CX-NDS8
O	TAPE DECK	C 0370	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0373	87-016-083-080	0E	C-CAP,S 0.15-16 K R	USM	CX-NDS8
O	TAPE DECK	C 0374	87-016-083-080	0E	C-CAP,S 0.15-16 K R	USM	CX-NDS8
O	TAPE DECK	C 0378	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0379	87-010-382-080	0E	CAP,E 22-25 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0380	87-010-382-080	0E	CAP,E 22-25 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0381	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0382	87-010-312-080	0E	C-CAP,S 15P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0383	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TAPE DECK	C 0384	87-010-402-080	0E	CAP,E 2.2-50 M 11L SME	USM	CX-NDS8
O	TAPE DECK	C 0386	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TAPE DECK	C 0387	87-012-145-080	0E	C-CAP,S 270P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0388	87-012-156-080	0E	C-CAP,S 220P-50 J CH GRM	USM	CX-NDS8
O	TAPE DECK	C 0391	87-010-319-080	0E	C-CAP,S 56P-50 J CH	USM	CX-NDS8
O	TAPE DECK	C 0392	87-010-319-080	0E	C-CAP,S 56P-50 J CH	USM	CX-NDS8
O	TAPE DECK	C 0393	87-010-319-080	0E	C-CAP,S 56P-50 J CH	USM	CX-NDS8
O	TAPE DECK	C 0394	87-010-319-080	0E	C-CAP,S 56P-50 J CH	USM	CX-NDS8
X	TAPE DECK	CLP0301	87-A60-884-010	0E	PIN,DIAL COATING-SHS	USM	CX-NDS8
X	TAPE DECK	CLP0302	87-A60-884-010	0E	PIN,DIAL COATING-SHS	USM	CX-NDS8
O	TAPE DECK	CN 0301	87-A60-620-010	0E	CONN,3P V 2MM JMT	USM	CX-NDS8
O	TAPE DECK	CN 0351	87-A60-625-010	0E	CONN,8P V 2MM JMT	USM	CX-NDS8
S	TAPE DECK	D 0352	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	TAPE DECK	D 0353	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	TAPE DECK	FB 0301	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
S	TAPE DECK	IC 0303	87-A20-783-040	1D	C-IC, BA7762AFS	USM	CX-NDS8
X	TAPE DECK	JR 0301	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0302	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0305	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0306	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0307	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0309	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0310	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0311	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0312	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0313	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0314	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0315	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0316	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0317	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0321	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0322	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0323	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0325	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0326	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0327	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0328	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0329	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0330	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0333	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0334	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0335	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0338	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
X	TAPE DECK	JR 0339	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0340	88-129-000-080	0E	C-JUMPER, 3216	USM	CX-NDS8
X	TAPE DECK	JR 0341	88-118-000-080	0E	C-JUMPER, S	USM	CX-NDS8
O	TAPE DECK	L 0301	87-A50-625-010	0E	COIL, TRAP 85KHZ (SANWA)	USM	CX-NDS8
O	TAPE DECK	L 0302	87-A50-625-010	0E	COIL, TRAP 85KHZ (SANWA)	USM	CX-NDS8
O	TAPE DECK	L 0351	87-007-342-010	0E	COIL, OSC 85KHZ BIAS	USM	CX-NDS8
S	TAPE DECK	Q 0351	87-A30-087-080	0E	C-FET, 2SK2158	USM	CX-NDS8
S	TAPE DECK	Q 0353	87-A30-087-080	0E	C-FET, 2SK2158	USM	CX-NDS8
S	TAPE DECK	Q 0354	87-A30-087-080	0E	C-FET, 2SK2158	USM	CX-NDS8
S	TAPE DECK	Q 0355	87-A30-063-080	0E	C-TR, KRA104S	USM	CX-NDS8
S	TAPE DECK	Q 0357	87-026-609-080	0E	TR, KTA1266GR	USM	CX-NDS8
S	TAPE DECK	Q 0358	87-026-610-080	0E	TR, KTC3198GR	USM	CX-NDS8
S	TAPE DECK	Q 0359	87-026-610-080	0E	TR, KTC3198GR	USM	CX-NDS8
S	TAPE DECK	Q 0361	87-A30-076-080	0E	C-TR, 2SC3052F	USM	CX-NDS8
S	TAPE DECK	Q 0381	87-A30-076-080	0E	C-TR, 2SC3052F	USM	CX-NDS8
S	TAPE DECK	Q 0382	87-A30-076-080	0E	C-TR, 2SC3052F	USM	CX-NDS8
S	TAPE DECK	Q 0383	87-A30-075-080	0E	C-TR, 2SA1235F	USM	CX-NDS8
X	TAPE DECK	R 0301	88-118-224-080	0E	C-RES, S 220K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0302	88-118-224-080	0E	C-RES, S 220K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0303	88-118-224-080	0E	C-RES, S 220K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0304	88-118-224-080	0E	C-RES, S 220K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0305	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0306	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0307	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0308	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0309	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0310	88-118-471-080	0E	C-RES, S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0311	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0312	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0314	88-118-223-080	0E	C-RES, S 22K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0315	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0316	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0317	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0318	88-118-562-080	0E	C-RES, S 5.6K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0319	88-118-223-080	0E	C-RES, S 22K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0320	88-118-223-080	0E	C-RES, S 22K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0323	88-118-392-080	0E	C-RES, S 3.9K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0324	88-118-392-080	0E	C-RES, S 3.9K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0328	88-118-473-080	0E	C-RES, S 47K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0329	88-118-473-080	0E	C-RES, S 47K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0332	88-118-223-080	0E	C-RES, S 22K-1/10W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	TAPE DECK	R 0333	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0335	88-121-223-080	0E	RES,22K-1/8W J	USM	CX-NDS8
X	TAPE DECK	R 0336	88-121-223-080	0E	RES,22K-1/8W J	USM	CX-NDS8
X	TAPE DECK	R 0337	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0338	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0350	88-130-180-080	0E	RES,18-1/4W J	USM	CX-NDS8
X	TAPE DECK	R 0351	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0352	88-118-152-080	0E	C-RES,S 1.5K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0353	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0354	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	TAPE DECK	R 0355	88-128-829-080	0E	C-RES, 8.2-1/8W J	USM	CX-NDS8
X	TAPE DECK	R 0356	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0357	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0359	88-128-100-080	0E	C-RES, 10-1/8W J	USM	CX-NDS8
X	TAPE DECK	R 0360	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0363	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0364	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TAPE DECK	R 0371	88-118-390-080	0E	C-RES,S 39-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0372	88-118-390-080	0E	C-RES,S 39-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0373	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0374	88-118-471-080	0E	C-RES,S 470-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0381	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0382	88-118-334-080	0E	C-RES,S 330K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0383	88-118-824-080	0E	C-RES,S 820K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0384	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0387	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0389	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0391	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0392	88-118-153-080	0E	C-RES,S 15K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0393	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TAPE DECK	R 0395	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0396	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0397	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	TAPE DECK	R 0398	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
O	TAPE DECK	SFR0351	87-A90-433-080	0E	SFR,50K H NVZ6TLTA	USM	CX-NDS8
O	TAPE DECK	SFR0352	87-A90-433-080	0E	SFR,50K H NVZ6TLTA	USM	CX-NDS8
X	TAPE DECK	SH 0301	87-MA6-202-010	0E	PLATE,SHLD DECK	USM	CX-NDS8
O	TUNER (IF)	C 0771	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0772	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0779	87-010-426-080	0E	C-CAP,S 0.012-25 K B	USM	CX-NDS8
O	TUNER (IF)	C 0780	87-010-426-080	0E	C-CAP,S 0.012-25 K B	USM	CX-NDS8
X	TUNER (IF)	C 0781	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER (IF)	C 0782	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0783	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0784	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0785	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0786	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0788	87-010-149-080	0E	C-CAP,S 5P-50 C CH GRM	USM	CX-NDS8
O	TUNER (IF)	C 0789	87-A10-592-080	0E	C-CAP,S 0.015-50 J B	USM	CX-NDS8
O	TUNER (IF)	C 0790	87-A10-592-080	0E	C-CAP,S 0.015-50 J B	USM	CX-NDS8
O	TUNER (IF)	C 0791	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (IF)	C 0792	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0793	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0795	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0796	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0797	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0798	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0799	87-010-407-080	0E	CAP,E 33-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0800	87-012-369-080	0E	C-CAP,S 0.047-50 Z F	USM	CX-NDS8
O	TUNER (IF)	C 0801	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0802	87-012-369-080	0E	C-CAP,S 0.047-50 Z F	USM	CX-NDS8
O	TUNER (IF)	C 0803	87-010-198-080	0E	C-CAP,S 0.022-25 K B C2012	USM	CX-NDS8
O	TUNER (IF)	C 0804	87-010-263-080	0E	CAP,E 100-10 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0807	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0808	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0809	87-010-401-080	0E	CAP,E 1-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0810	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (IF)	C 0811	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0812	87-010-403-080	0E	CAP,E 3.3-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0814	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	TUNER (IF)	C 0815	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0816	87-010-400-080	0E	CAP,E 0.47-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0821	87-010-405-080	0E	CAP,E 10-50 M 11L SME	USM	CX-NDS8
X	TUNER (IF)	C 0822	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER (IF)	C 0823	87-010-177-080	0E	C-CAP,S 820P-50 J SL C2012	USM	CX-NDS8
O	TUNER (IF)	C 0824	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	TUNER (IF)	C 0825	87-010-596-080	0E	C-CAP,S 0.047-16 K R C2012	USM	CX-NDS8
X	TUNER (IF)	D 0801	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
S	TUNER (IF)	D 0803	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	TUNER (IF)	IC 0801	87-A21-560-010	1C	IC,LA1844L-A	USM	CX-NDS8
X	TUNER (IF)	JR 0780	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	TUNER (IF)	JR 0781	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	TUNER (IF)	JR 0785	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0786	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0790	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0792	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0795	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0797	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0801	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0821	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	JR 0822	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER (IF)	L 0801	87-A50-608-010	0E	COIL,FM DET-N(TOK)	USM	CX-NDS8
O	TUNER (IF)	L 0802	87-A91-551-010	1A	FLTR,PCFJZH-450 L(TOK)	USM	CX-NDS8
O	TUNER (IF)	L 0811	87-005-847-080	0E	COIL,2,2UH K CECS	USM	CX-NDS8
S	TUNER (IF)	Q 0801	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
S	TUNER (IF)	Q 0802	87-A30-076-080	0E	C-TR,2SC3052F	USM	CX-NDS8
X	TUNER (IF)	R 0773	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0774	88-118-222-080	0E	C-RES,S 2.2K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0775	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0776	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
O	TUNER (IF)	R 0790	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
X	TUNER (IF)	R 0791	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0793	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	R 0795	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	R 0801	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0802	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0803	88-128-183-080	0E	C-RES, 18K-1/8W J	USM	CX-NDS8
X	TUNER (IF)	R 0804	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	R 0805	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0806	88-118-682-080	0E	C-RES,S 6.8K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0807	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0808	88-118-821-080	0E	C-RES,S 820-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0809	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0810	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0811	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0812	88-118-474-080	0E	C-RES,S 470K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0813	88-118-224-080	0E	C-RES,S 220K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0814	88-118-105-080	0E	C-RES,S 1M-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0815	88-121-682-080	0E	RES,6.8K-1/8W J	USM	CX-NDS8
X	TUNER (IF)	R 0818	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0821	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (IF)	R 0823	88-118-333-080	0E	C-RES,S 33K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0824	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0825	88-118-473-080	0E	C-RES,S 47K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0826	88-118-223-080	0E	C-RES,S 22K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0827	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
X	TUNER (IF)	R 0828	88-118-332-080	0E	C-RES,S 3.3K-1/10W J	USM	CX-NDS8
O	TUNER (PLL)	C 0971	87-010-381-080	0E	CAP,E 330-16 M SME	USM	CX-NDS8
O	TUNER (PLL)	C 0972	87-010-404-080	0E	CAP,E 4.7-50 M 11L SME	USM	CX-NDS8
O	TUNER (PLL)	C 0973	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0974	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0979	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
O	TUNER (PLL)	C 0981	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
O	TUNER (PLL)	C 0982	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0983	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0984	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0987	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0991	87-010-312-080	0E	C-CAP,S 15P-50 J CH GRM	USM	CX-NDS8
O	TUNER (PLL)	C 0992	87-010-312-080	0E	C-CAP,S 15P-50 J CH GRM	USM	CX-NDS8
O	TUNER (PLL)	C 0993	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	TUNER (PLL)	C 0995	87-010-178-080	0E	C-CAP,S 1000P-50 K B C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0997	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (PLL)	C 0998	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
O	TUNER (PLL)	C 0999	87-A11-155-080	0E	CAP,TC U 0.01-16 Z F	USM	CX-NDS8
S	TUNER (PLL)	D 0804	87-020-465-080	0E	DIODE,1SS133	USM	CX-NDS8
S	TUNER (PLL)	D 0991	87-017-149-080	0E	ZENER,HZS6A2L	USM	CX-NDS8
S	TUNER (PLL)	IC 0991	87-070-127-110	1C	IC,LC72131D	USM	CX-NDS8
X	TUNER (PLL)	JR 0962	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (PLL)	JR 0971	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	TUNER (PLL)	JR 0972	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (PLL)	JR 0973	88-129-000-080	0E	C-JUMPER,3216	USM	CX-NDS8
X	TUNER (PLL)	JR 0974	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (PLL)	JR 0976	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (PLL)	JR 0977	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (PLL)	JR 0988	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
S	TUNER (PLL)	Q 0981	87-A30-234-080	0E	TR,CSC4115BC	USM	CX-NDS8
X	TUNER (PLL)	R 0975	88-118-562-080	0E	C-RES,S 5.6K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0976	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0977	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0978	88-118-681-080	0E	C-RES,S 680-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0980	88-118-684-080	0E	C-RES,S 680K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0981	88-121-471-080	0E	RES,470-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0982	88-118-822-080	0E	C-RES,S 8.2K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0983	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0984	88-121-181-080	0E	RES,180-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0985	88-121-471-080	0E	RES,470-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0986	88-128-222-080	0E	C-RES, 2.2K-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0987	88-121-472-080	0E	RES,4.7K-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0988	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0989	88-121-102-080	0E	RES,1K-1/8W J	USM	CX-NDS8
X	TUNER (PLL)	R 0990	88-118-563-080	0E	C-RES,S 56K-1/10W J	USM	CX-NDS8
O	TUNER (PLL)	R 0991	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
X	TUNER (PLL)	R 0992	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
O	TUNER (PLL)	R 0993	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
X	TUNER (PLL)	R 0994	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
O	TUNER (PLL)	R 0995	87-010-322-080	0E	C-CAP,S 100P-50 J CH GRM	USM	CX-NDS8
X	TUNER (PLL)	R 0996	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0997	88-118-154-080	0E	C-RES,S 150K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0998	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER (PLL)	R 0999	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
O	TUNER (PLL)	X 0991	87-A70-061-010	1A	VIB,XTAL 4.500MHZ CSA-309	USM	CX-NDS8
X	TUNER (RDS)	JR 0871	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (RDS)	JR 0873	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER (RF)	C 0842	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0843	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0844	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0845	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0846	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0847	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0848	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0849	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0850	87-010-260-080	0E	CAP,E 47-25 M 11L SME	USM	CX-NDS8
O	TUNER (RF)	C 0851	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0852	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0853	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
O	TUNER (RF)	C 0858	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (RF)	C 0859	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (RF)	C 0860	87-010-197-080	0E	C-CAP,S 0.01-25 K B C2012	USM	CX-NDS8
X	TUNER (RF)	C 0940	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER (RF)	C 0959	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (RF)	C 0960	87-010-196-080	0E	C-CAP,S 0.1-25 Z F C2012	USM	CX-NDS8
O	TUNER (RF)	C 0961	87-010-152-080	0E	C-CAP,S 8P-50 D CH GRM	USM	CX-NDS8
O	TUNER (RF)	C 0963	87-015-785-080	0E	C-CAP, 0.1-25 Z F C3216	USM	CX-NDS8
O	TUNER (RF)	CF 0831	87-008-261-010	1A	FLTR,CF SFE10.7MA5	USM	CX-NDS8
O	TUNER (RF)	CF 0832	87-008-261-010	1A	FLTR,CF SFE10.7MA5	USM	CX-NDS8
X	TUNER (RF)	D 0944	88-100-000-010	0E	PLATING-JW, 0.58 SN95	USM	CX-NDS8
X	TUNER (RF)	FFE0831	A8-6ZA-19H-030	-	6ZA-1 FEMENM	USM	CX-NDS8
!	O	J 0831	87-A60-202-010	1A	TERMINAL,ANT 4P MSP-154V-02	USM	CX-NDS8
X	TUNER (RF)	JR 0834	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER (RF)	JR 0835	88-128-561-080	0E	C-RES, 560-1/8W J	USM	CX-NDS8

PARTS LIST

! = Δ SAFTY PARTS
 C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.


Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.


! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	TUNER(RF)	JR 0836	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0943	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0946	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0951	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0952	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0954	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
X	TUNER(RF)	JR 0955	88-118-000-080	0E	C-JUMPER,S	USM	CX-NDS8
O	TUNER(RF)	L 0832	87-005-847-080	0E	COIL,2.2UH K CECS	USM	CX-NDS8
O	TUNER(RF)	L 0951	8A-NF8-667-010	1C	COIL,AM PACK 4(TOK)	USM	CX-NDS8
S	TUNER(RF)	Q 0835	89-327-143-080	0E	C-TR,2SC27140	USM	CX-NDS8
S	TUNER(RF)	Q 0836	87-A30-489-080	0E	C-TR,KRA107S	USM	CX-NDS8
X	TUNER(RF)	R 0832	88-118-391-080	0E	C-RES,S 390-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0836	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0839	88-118-151-080	0E	C-RES,S 150-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0840	88-118-221-080	0E	C-RES,S 220-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0850	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0851	88-118-470-080	0E	C-RES,S 47-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0852	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0853	88-118-102-080	0E	C-RES,S 1K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0854	88-118-331-080	0E	C-RES,S 330-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0855	88-118-183-080	0E	C-RES,S 18K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0856	88-118-103-080	0E	C-RES,S 10K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0857	88-118-181-080	0E	C-RES,S 180-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0858	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0860	88-118-101-080	0E	C-RES,S 100-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0945	88-118-104-080	0E	C-RES,S 100K-1/10W J	USM	CX-NDS8
X	TUNER(RF)	R 0962	88-121-221-080	0E	RES,220-1/8W J	USM	CX-NDS8
X	TUNER(RF)	R 0963	88-118-330-080	0E	C-RES,S 33-1/10W J	USM	CX-NDS8
X	TUNER(RF)	SH 0831	87-A90-023-010	0E	SHLD-PLATE,ANT	USM	CX-NDS8

SCHEMATIC DIAGRAM - 1 (MAIN 1/3)



S.TAKE S.TAKE
 (MAIN)
 SCHEMATIC DIAGRAM
 8A NFG 631 01
 C0000900
 CX-N958
 27 JUN 2000

SCHEMATIC DIAGRAM - 2 (MAIN 2/3 : DECK SECTION)



B-ANF-16MAIN (P2)

	WITH DOLBY	W/O DOLBY (R+R)
JR303	C-JR	X
JR304	C-JR	X
C379	X	22/25
C380	X	22/50
C313	1200P	1000P
C314	1200P	1000P
R315	4.7K	5.6K
R316	4.7K	5.6K
R317	5.6K	5.6K
R318	5.6K	5.6K
C391	270P	56P
C392	270P	56P
C393	270P	56P
C394	270P	56P
R395	X	100K
R396	X	100K
R397	X	100K
R398	X	100K
SFR301	33K	X
SFR302	33K	X
SFR303	33K	X
SFR304	33K	X
C317	0.33 BK	C-JR
C318	0.33 BK	C-JR
R371	4.7K	39
R372	4.7K	39
C375	0.22/50	X
C376	0.22/50	X
R375	18K	X
JR301	X	C-JR
JR302	X	C-JR

	USE BA7762AFS	USE HA12211
Q360	X	25K2158
R330	X	C-JR
R331	X	33K
JR336	X	C-JR

	WITH DOLBY	W/O DOLBY (R+R, L+L+I)
IC302	CXA1553P	X
C309	X	0.1
C310	X	0.1
C319	0.22	X
C320	0.22	X
R321	4.7K	X
R322	4.7K	X
SFR305	50K	X
SFR306	50K	X
C371	560P	X
C372	560P	X
C373	1200P	0.15
C374	1200P	0.15
R319	8.2K	22K
R320	8.2K	22K
R323	22K	3.9K
R324	22K	3.9K
C321	0.22	0.33
C322	0.22	0.33
R335	27K	22K
R336	27K	22K
R391	X	15K
R392	X	15K
R385	15K	X
R386	15K	X
R383	470K	820K
C387	X	270P
C382	47P	15P
R389	C-JR	6.8K
Q383	X	25A1235
C385	3300P	X

	EZ K MODEL	EXCEPT EZ K
Q356	25C3052F	X
R362	4.7K	X
R365	10K	X

	EZ K MODEL	EXCEPT EZ
FB301	EM1BL01RN1	JW

S.TAKE S.TAKE
SCHEMATIC DIAGRAM (DECK)
8A NFG 631 01

SCHEMATIC DIAGRAM - 3 (MAIN 3/3 : TUNER SECTION)





IFT COIL

	PARTS NO./ PARTS CODE		
	U/LH, EZ, K, G, V	HE/HR/HC	Ð/HÐ
1ST	87-A91-551-01 FLTR. PCFJZH-450 L (TOK)	87-A91-552-01 FLTR. CFMT-450AL (TOK)	87-A91-553-01 FLTR. PCFMT-060L (TOK)
2ND			
3RD			

AM PACK


	PARTS NO./ PARTS CODE	
	U/LH, Ð/HÐ, V	EZ, K, G
1ST	8A-NFB-667-01 COIL. AM PACK4 (TOK)	8A-NFB-668-01 COIL. AM PACK (TOK)
2ND		
3RD		

*EXCEPT SW BAND MODEL (HE/HR/HC)



S. TAKE S. TAKE (TUNER) SCHEMATIC DIAGRAM 8A NFG 631 01

SCHEMATIC DIAGRAM - 4 (FRONT)




ANF-16
DOLBY DIGITAL

PWB FRONT

T. HOJO T. HOJO
SCHEMATIC DIAGRAM
8A NFG 601 01

SCHEMATIC DIAGRAM - 5 (AMP)




T.H0J0 T.H0J0
AMP (1F)
8A NF6 650 11

D-ANF-26AMP-1F-U

ANF-16 U CX-NDS8 U
16 JUN 2000

SCHEMATIC DIAGRAM - 6 (PRO LOGIC)



T.HOJO T.HOJO
AMP (2F)

8A NF6 655 21

C0000432


ANF-16 U

CX-NB58 U

10 MAR 2000

0-ANF-16AMP-PL0G1C-U

SCHEMATIC DIAGRAM - 7 (PT)




D-ANF-16PT-U

ANF-16

S.TAKE S.TAKE
 SCHEMATIC DIAGRAM (PT)
 8A NF6 641 11

CX-NØS8 U
 30 MAY 2000

SCHEMATIC DIAGRAM - 8 (AC3)



B-ANF-16AC3

S.TAKE S.TAKE

SCHEMATIC DIAGRAM

8Z NFD 650 11


C000923

ANF - 16

CX - ND58

28 JUN 2000

SCHEMATIC DIAGRAM - 9 (DOLBY DIGITAL)



S. TAKE S. TAKE
(DOLBY DIGITAL)
SCHEMATIC DIAGRAM

8A NFG 634 01

C0000920

CX-NDS8

27 JUN 2000

ANF-16

B-ANF-16MAIN (P3)

アイワ株式会社 東京都台東区根岸1-11-11 電話 03(3827)3111 (株券)
AIWA CO., LTD. 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111